



FCAR F3 Diagnostic List (Note: For reference only)

Automaker: citroen
Version: v8.2

Menu	System	Function							
		Version Info.	Read DTC	Clear DTC	Read Data Stream	Action test	Remark		
C-ZERO	Built-in Systems interface		√	√	√	√	-	-	
	Calculateur de controle machine electrique		√	√	√	√	-	-	
	Traction battery ECU		√	√	√	√	-	-	
	Electric vehicle management ECU		√	√	√	-	-	-	
	ESP		√	√	√	√	-	-	
	Power steering		√	√	√	√	-	-	
	Steering wheel angle sensor		√	√	√	√	-	-	
	Airbag	SRC	√	√	√	√	-	-	
		ORC	√	√	√	√	-	-	
	Gateway wiring housing		√	√	√	√	-	-	
	Independent telematic unit(BTA)		√	√	√	√	-	-	
	Instrument panel		√	√	√	√	-	-	
	Radio		√	√	√	√	-	-	
	Air conditioning		√	√	√	√	-	-	
	Air conditioning compressor and passenger compartment		√	√	√	√	-	-	
Onboard charger of the traction battery		√	√	√	√	-	-		
Direct voltage(DC/DC)transformer		-	√	√	√	-	-		
C1	Injection	Petrol engine 384 F injection	-	-	-	√	-	-	
		Diesel engine DV4 injection	√	√	-	√	-	-	
	Gearbox ECU		√	√	√	-	-	-	
	ABS	ABS anti-lock braking system	-	√	√	√	-	-	
		ESP S2000 ABS	-	√	√	√	-	ESP Calibrat ion	
	Airbag		√	√	√	√	-	-	
Immobiliser control module(Immobiliser)		-	√	√	√	-	-		
Electric power steering		√	√	√	√	-	-		
C2 (Before 1 September 2005)	Radio	BSI	√	√	√	√	-	-	
		Instrument panel	√	√	√	√	√	-	
	Radio	Radio post-equipment	√	√	√	√	√	-	
		CD player	√	√	√	√	√	-	
	Parking assistance		√	-	√	√	√	-	
	Air conditioning		√	√	-	√	-	-	
	Navigation		√	√	√	√	-	-	
	Alarm		√	-	√	-	√	-	
	Switch module under the steering wheel	Top of column		√	-	-	√	-	-
				√	-	-	√	-	-
	Rain sensor/Brightness		√	-	-	-	-	-	
	Airbag		√	√	-	√	-	-	
	Display or Telematics	Multifunction display SAGEM A		√	√	√	√	√	-
		Multifunction display SAGEM B		√	√	√	√	√	-
		Multifunction display SAGEM C		√	√	√	√	√	-
		Telematics unit independent		√	√	√	√	√	-
	Injection	Petrol engine	HFX MM48P	√	√	√	√	√	Initiali sation of auto-adaptati on
			NFU BOSCH ME744	√	√	√	√	√	Initiali sation of auto-adaptati on
			NFS BOSCH ME744	√	√	√	√	√	Initiali sation of auto-adaptati on
			KFV SAGEM S2000PM1	√	√	√	√	√	-
KFV SAGEM S2000PM2			√	√	√	√	-	-	
8HZ BOSCH EDC16C34 DV4TD			√	√	√	√	√	-	
Diesel engine		8HX BOSCH EDC16C34 DV4TD	√	√	√	√	√	-	
		8HX SIEMENS SID802	√	√	√	√	√	-	
		8HX SIEMENS SID804	√	√	√	√	√	-	
		8HZ SIEMENS SID804	-	-	√	-	-	-	
Anti-lock brake system	ABS	√	√	-	√	-	-		
	ESP	√	√	√	√	√	ESP Calibrat ion		

	Gearbox ECU	Controlled manual gearbox ECU MA	✓	✓	✓	✓	-	Learning		
		Electric power steering ECU	✓	✓	✓	✓	-	-		
		BSI	✓	✓	✓	✓	-	-		
		Instrument panel	✓	✓	✓	✓	-	-		
		Radio	✓	✓	✓	✓	✓	-		
		CD player	✓	✓	✓	✓	✓	-		
		Parking assistance	✓	✓	✓	✓	✓	-		
		Air conditioning	✓	✓	✓	✓	-	-		
		Alarm	✓	✓	✓	✓	✓	-		
		Switch module under the steering wheel	✓	✓	✓	✓	✓	-		
		Rain sensor/Brightness	✓	✓	✓	-	-	-		
		Airbag	✓	✓	✓	✓	-	-		
	Multifunction screen	Multifunction screen A	✓	✓	✓	✓	-	-		
		Multifunction screen C	✓	✓	✓	✓	✓	-		
	Telematic	Telematics (RT3)	✓	✓	✓	✓	✓	-		
		Telematics (RT3)	✓	✓	✓	✓	✓	-		
		Telematics (RT3)	✓	✓	✓	✓	✓	-		
		High frequency receiver	✓	✓	✓	✓	-	-		
C2 (After 1 September 2005)	Injection	Petrol engine	KFU MM6LPC	✓	✓	✓	✓	-	Initialisation of auto-adaptation	
			TU1A J34P	✓	✓	✓	✓	-	Initialisation of auto-adaptation	
			TU3A J34P	✓	✓	✓	✓	-	Initialisation of auto-adaptation	
			NFS BOSCH ME745	✓	✓	✓	✓	✓	Initialisation of auto-adaptation	
			NFU BOSCH ME745	✓	✓	✓	✓	✓	Initialisation of auto-adaptation	
			N6A BOSCH ME745	✓	✓	✓	✓	✓	Initialisation of auto-adaptation	
			NFR BOSCH ME745	✓	✓	✓	✓	✓	Initialisation of auto-adaptation	
			KFV SAGEM S2000PM2	✓	✓	✓	✓	-	-	
		Diesel engine	(FAP) BOSCH EDC16C34 DV6T	✓	✓	✓	✓	✓	Specific operation for maintenance and part replacement	
			8HZ BOSCH EDC16C34 DV4TD	✓	✓	✓	✓	✓	-	
			8HZ SIEMENS SID806	✓	✓	✓	✓	-	-	
				Trailer relay unit	✓	✓	✓	✓	✓	-
				Engine relay unit	✓	✓	✓	✓	✓	-
		Anti-lock brake system		ABS MK70	✓	✓	✓	✓	-	-
				ABS MK70.1	✓	✓	✓	✓	-	-
	ESP MK60		✓	✓	✓	✓	-	ESP Calibration		
	ESP MK60-0		✓	✓	✓	✓	-	ESP Calibration		
	Gearbox ECU	Controlled manual gearbox ECU MA	✓	✓	✓	✓	-	-		
		Electric power steering ECU	✓	✓	✓	✓	-	-		
		Hands Free Kit	✓	✓	✓	✓	✓	-		
		ECU Reversible "Stop-Start" alternator	✓	✓	✓	✓	-	-		

C2 CHINE	BSI		✓	✓	✓	✓	-	-	
	Instrument panel		✓	✓	✓	✓	✓	-	
	Air conditioning		✓	✓	✓	✓	-	-	
	ABS		✓	✓	✓	✓	-	-	
	Steering wheel with fixed central controls		✓	✓	✓	✓	-	-	
	Airbag		✓	✓	✓	✓	-	-	
	Injection	Petrol engine	1.6L NFU BOSCH ME745	✓	✓	✓	✓	✓	Initialise auto-adaptatives
J34P			✓	✓	✓	✓	✓	Initialise auto-adaptatives	
Gearbox ECU		✓	✓	✓	✓	✓	-		
C3	BSI		✓	✓	✓	✓	-	-	
	Instrument panel		✓	✓	✓	✓	✓	-	
	Radio	Radio post-equipment	✓	✓	✓	✓	✓	-	
		Radio post-equipment RDE Wire	✓	✓	✓	✓	-	-	
	CD player		✓	✓	✓	✓	✓	-	
	Parking assistance		✓	-	✓	✓	✓	-	
	Air conditioning		✓	✓	-	✓	-	-	
	Navigation		✓	✓	✓	✓	-	-	
	Alarm		✓	-	✓	-	✓	-	
	Switch module under the steering wheel		✓	-	-	✓	-	-	
	Diesel additive funtion		✓	✓	-	✓	✓	-	
	Rain sensor/Brightness		✓	-	✓	-	-	-	
	Driving school mode		✓	-	-	✓	-	-	
	Airbag		✓	✓	-	✓	-	-	
	Multifunction display	Multifunction display SAGEM A		✓	✓	✓	✓	✓	-
		Multifunction display SAGEM B		✓	✓	✓	✓	✓	-
		Multifunction display SAGEM C		✓	✓	✓	✓	✓	-
		Telematics unit		✓	✓	✓	✓	✓	-
	Service module		✓	✓	✓	✓	-	-	
	Injection	Petrol engine	HFV MM48P	✓	✓	✓	✓	✓	Initialisation of auto-adaptation
NFU BOSCH ME744			✓	✓	✓	✓	✓	Initialisation of auto-adaptation	
KFV SAGEM S2000PM1			✓	✓	✓	✓	✓	-	
KFV SAGEM S2000PM2			✓	✓	✓	✓	✓	-	
NFU BOSCH ME749			✓	✓	✓	✓	✓	Initialisation of auto-adaptation	
N6A BOSCH ME749			✓	✓	✓	✓	✓	Initialisation of auto-adaptation	
NFS BOSCH ME749			✓	✓	✓	✓	✓	Initialisation of auto-adaptation	
NFR BOSCH ME749			✓	✓	✓	✓	✓	Initialisation of auto-adaptation	
		KFV BOSCH ME749	✓	✓	✓	✓	Initialisation of auto-adaptation		

C3 R	Diesel engine	HX BOSCH EDC16C34 DV6ATED	✓	✓	✓	✓	-	Specific operation for maintenance and part replacement
		8HZ BOSCH EDC16C34 DV4TD	✓	✓	✓	✓	✓	-
		8HX BOSCH EDC16C34 DV4TD	✓	✓	✓	✓	✓	-
		8HX SIEMENS SID802	✓	✓	✓	✓	✓	-
		8HX SIEMENS SID804	✓	✓	✓	✓	✓	-
		8HZ SIEMENS SID806	✓	✓	✓	✓	✓	-
		8HY DELPHI C6	✓	✓	✓	✓	✓	-
	Gas injection	SAX500 GPL	✓	✓	✓	✓	-	-
		SAX500 GNV	✓	✓	✓	✓	-	-
	Anti-lock brake system	ABS MK60	✓	✓	✓	✓	-	-
		ABS MK70	✓	✓	✓	✓	-	-
		ESP	✓	✓	✓	✓	✓	ESP Calibration
	Gearbox ECU	Auto gearbox AL4	✓	✓	✓	✓	✓	-
		Controlled manual gearbox ECU MA	✓	✓	✓	✓	-	Learning
	Electric power steering ECU		✓	✓	✓	✓	-	-
	ECU Reversible "Stop-Start" alternator		✓	✓	✓	✓	-	-
	BSI		✓	✓	✓	✓	-	-
	Instrument panel		✓	✓	✓	✓	-	-
	Radio		✓	✓	✓	✓	✓	-
	CD player		✓	✓	✓	✓	✓	-
	Parking assistance		✓	✓	✓	✓	✓	-
Air conditioning		✓	✓	✓	✓	-	-	
Alarm		✓	✓	✓	✓	✓	-	
Switch module under the steering wheel		✓	✓	✓	✓	✓	-	
Rain sensor/Brightness		✓	✓	✓	-	-	-	
Airbag		✓	✓	✓	✓	-	-	
Driving school mode		✓	✓	✓	-	-	-	
Multifunction screen	Multifuntion screen A	✓	✓	✓	✓	-	-	
	Multifuntion screen C	✓	✓	✓	✓	✓	-	
Telematic	Telematics (RT3)	✓	✓	✓	✓	✓	-	
	Telematics (RT4)	✓	✓	✓	✓	✓	-	
	Telematics (RT5)	✓	✓	✓	✓	✓	-	
High frequency receiver		✓	✓	✓	✓	-	-	
Injection	Petrol engine	TU1A J34P	✓	✓	✓	✓	-	Initialisation of auto-adaptation
		TU3A J34P	✓	✓	✓	✓	-	Initialisation of auto-adaptation
		KFU MM6LPC	✓	✓	✓	✓	-	Initialisation of auto-adaptation
		NFS BOSCH ME745	✓	✓	✓	✓	✓	Initialisation of auto-adaptation
		NFU BOSCH ME745	✓	✓	✓	✓	✓	Initialisation of auto-adaptation
		N6A BOSCH ME745	✓	✓	✓	✓	✓	Initialisation of auto-adaptation
		NFR BOSCH ME745	✓	✓	✓	✓	✓	Initialisation of auto-adaptation
		KFV SAGEM S2000PM2	✓	✓	✓	✓	-	-

		8HZ BOSCH EDC16C34 DV4TD	✓	✓	✓	✓	✓	–		
	Diesel engine	(FAP) BOSCH EDC16C34 DV6TE							Specific operation for maintenance and part replacement	
		8HX BOSCH EDC16C34 DV6ATED							Specific operation for maintenance and part replacement	
		8HZ SIEMENS SID806	✓	✓	✓	✓	✓	–	–	
Gas injection	SAX500 GPL		✓	✓	✓	✓	✓	–	–	
	SAX500 GNV		✓	✓	✓	✓	✓	–	–	
Multiplexed diesel additive pump			✓	✓	✓	✓	✓	–	–	
Trailer relay unit			✓	✓	✓	✓	✓	–	–	
Engine relay unit			✓	✓	✓	✓	✓	–	–	
Anti-lock brake system	ABS MK70		✓	✓	✓	✓	✓	–	–	
	ABS MK70.1		✓	✓	✓	✓	✓	–	–	
	ESP MK60		✓	✓	✓	✓	–	–	ESP Calibration	
	ESP MK60-0		✓	✓	✓	✓	–	–	ESP Calibration	
Gearbox ECU	Auto gearbox A14		✓	✓	✓	✓	✓	–	Learning	
	Controlled manual gearbox ECU MA								Initialisation of auto-adaptation	
Electric power steering ECU			✓	✓	✓	✓	–	–		
Hands Free Kit			✓	✓	✓	✓	✓	–		
ECU Reversible "Stop-Start" alternator			✓	✓	✓	✓	–	–		
C3 PLURIEL (Before 1 September 2005)	BSI		✓	✓	✓	✓	–	–	–	
	Instrument panel		✓	✓	✓	✓	✓	–	–	
	Radio		✓	✓	✓	✓	✓	–	–	
	CD player		✓	✓	✓	✓	✓	–	–	
	Parking assistance		✓	–	✓	✓	✓	–	–	
	Air conditioning		✓	✓	–	✓	–	–	–	
	Navigation		✓	✓	✓	✓	–	–	–	
	Alarm		✓	–	✓	–	✓	–	–	
	Switch module under the steering wheel		✓	–	–	✓	✓	–	–	
	Rain sensor / Brightness		✓	–	–	–	–	–	–	
	Sun roof		✓	✓	–	✓	–	–	–	
	Driving school mode		✓	–	✓	✓	–	–	–	
	Airbag		✓	✓	–	✓	–	–	–	
	Display or Telematics	Multifunction display SAGEM A		✓	✓	✓	✓	✓	–	–
		Multifunction display SAGEM B		✓	✓	✓	✓	✓	–	–
		Multifunction display SAGEM C		✓	✓	✓	✓	✓	–	–
		Telematics unit		✓	✓	✓	✓	✓	–	–
Injection	Petrol engine	NFU BOSCH ME744	✓	✓	✓	✓	✓	–	Initialisation of auto-adaptation	
		KFV SAGEM S2000PM1	✓	✓	✓	✓	✓	–	–	
		KFV SAGEM S2000PM2	✓	✓	✓	✓	–	–	–	
	Diesel engine	8HZ BOSCH EDC16C34 DV4TD	✓	✓	✓	✓	✓	–	–	
		8HX SIEMENS SID802	✓	✓	✓	✓	✓	–	–	
		8HX SIEMENS SID804	✓	✓	✓	✓	✓	–	–	
Anti-lock brake system	ABS		✓	✓	✓	✓	–	–		
	ESP		✓	✓	✓	✓	✓	–	ESP Calibration	
Gearbox ECU			✓	✓	✓	✓	–	Learning		
Electric power steering ECU			✓	✓	✓	✓	–	–		
	BSI		✓	✓	✓	✓	–	–	–	
	Instrument panel		✓	✓	✓	✓	–	–	–	
	Radio		✓	✓	✓	✓	✓	–	–	
	CD player		✓	✓	✓	✓	✓	–	–	
	Parking assistance		✓	✓	✓	✓	✓	–	–	

C3 PLURIEL
(After 1
September
2005)

Air conditioning		✓	✓	✓	✓	-	-	
Alarm		✓	✓	✓	✓	-	-	
Switch module under the steering wheel		✓	✓	✓	✓	-	-	
Rain sensor/Brightness		✓	✓	✓	-	-	-	
Sun roof		✓	✓	✓	✓	-	-	
Airbag		✓	✓	✓	✓	-	-	
Multifunction screen	Multifunction screen A	✓	✓	✓	✓	-	-	
	Multifunction screen C	✓	✓	✓	✓	✓	-	
Telematic	Telematics (RT3)	✓	✓	✓	✓	✓	-	
	Telematics (RT4)	✓	✓	✓	✓	✓	-	
	Telematics (RT5)	✓	✓	✓	✓	✓	-	
	RNEG navigation radio	✓	✓	✓	✓	-	-	
High frequency receiver		✓	✓	✓	✓	-	-	
Injection	Petrol engine	TU1A J34P	✓	✓	✓	✓	-	Initiali- sation of auto- adaptati- on
		TU3A J34P	✓	✓	✓	✓	-	Initiali- sation of auto- adaptati- on
		NFS BOSCH ME745	✓	✓	✓	✓	✓	Initiali- sation of auto- adaptati- on
		NFU BOSCH ME745	✓	✓	✓	✓	✓	Initiali- sation of auto- adaptati- on
		N6A BOSCH ME745	✓	✓	✓	✓	✓	Initiali- sation of auto- adaptati- on
	NFR BOSCH ME745	✓	✓	✓	✓	✓	Initiali- sation of auto- adaptati- on	
Diesel engine	8HZ BOSCH EDC16C34 DV4TD	✓	✓	✓	✓	-	-	
	8HZ SIEMENS SID806	✓	✓	✓	✓	-	-	
Trailer relay unit		✓	✓	✓	✓	✓	-	
Engine relay unit		✓	✓	✓	✓	✓	-	
Anti-lock brake system	ABS MK70	✓	✓	✓	✓	-	-	
	ABS MK70.1	✓	✓	✓	✓	-	-	
	ESP MK60	✓	✓	✓	✓	-	-	
	ESP MK60-0	✓	✓	✓	✓	-	-	
Gearbox ECU	Controlled manual gearbox ECU MA	✓	✓	✓	✓	✓	Learning	
Electric power steering ECU		✓	✓	✓	✓	-	-	
Hands Free Kit		✓	✓	✓	✓	✓	-	
Built-in Systems Interface		✓	✓	✓	✓	-	-	
Engine ECU	MEV17_4_2	✓	✓	✓	✓	✓	Initiali- sing the autoadap- tives	
	MEV17_4_EURO5	✓	✓	✓	✓	✓	Initiali- sing the autoadap- tives	
	EDC16C3	✓	✓	✓	✓	✓		
	EDC17C10	✓	✓	✓	✓	✓		
	EDC17C10_BR2	✓	✓	✓	✓	✓	Initiali- sation of the autoadap- tive values	
	EDC16C3DV4	✓	✓	✓	✓	✓		
V341	✓	✓	✓	✓	✓	Initiali- sing the autoadap- tives		

C3 (A51)		J34P						Initialising the autoadap tives	
		HDI_SID807	√	√	√	√	√		
		HDI_SID807_BR2						Initialising the autoadap tives	
		V46	√	√	√	√	√		
	ABS/ESP		ABS MK70. 2	√	√	√	√	√	Bleeding
			ESP MK60 0	√	√	√	√	√	Bleeding
			ABS MK100	√	√	√	√	√	Bleeding
			ESP MK100	√	√	√	√	√	Bleeding
	Gearbox		BVA_AL4						Initialising the autoadap tives
			BVMP_MA	√	√	√	√	√	-
			CFC300P	√	√	√	√	√	-
			MAPS_UDS	√	√	√	√	√	-
		Electro-hydraulic power steering (GEP)	√	√	√	√	√	-	
		Multiplexed additive pump	√	√	√	√	√	-	
	Battery charge status unit		BECE	√	√	√	√	-	-
			BECE GEN2	√	√	√	√	-	-
		Trailer relay unit	√	√	√	√	-	-	
		Engine relay unit	√	√	√	√	-	-	
		Air bag	√	√	√	√	-	-	
		Switch module at the steering wheel	√	√	√	√	√	-	
		Parking aid	√	√	√	√	-	-	
		Air conditioning ECU	√	√	√	√	√	-	
	Multifunction display		Type "A" (segments) AVEC buttons	√	√	√	√	√	-
			Type "A" (segments) SANS buttons	√	√	√	√	√	-
			Type "C" (dot matrix)	√	√	√	√	√	-
			Type "C colour" (dot matrix)	√	√	√	√	√	-
		Instrument panel	√	√	√	√	√	-	
		Hands-free kit (Telephone)	√	√	√	√	√	-	
	Telematics		RADIONAV_RNEGC	√	√	√	√	√	-
			RNEG2010	√	√	√	√	√	-
Radio		RD4	√	√	√	√	√	-	
		RD45	√	√	√	√	√	-	
Alarm		Alarm with anti-lift module	√	√	√	√	√	-	
	Driver's door module	√	√	√	√	√	-		
	Seat belts not fastened LED unit	√	-	-	-	-	-		
	Driving school module	√	-	-	-	-	-		
	Rain sensor	√	√	√	√	-	-		
	High frequency receiver	√	√	√	√	-	-		
	Service module	√	√	√	√	√	-		
	Central voltage retention device	√	√	√	-	-	-		
C3 Ai51		Built-in Systems Interface (BSI)	-	-	-	-	-	-	
	Injection/ignition		ME749	√	√	√	√	-	
			ME749_EC5	√	√	√	√	-	
			V34.4	√	√	√	√	-	
			V34.5	√	√	√	√	-	
	ABS/ASR		ABSMK70 1	√	√	√	√	-	
			ESPMK60 0	√	√	√	√	-	
		Gearbox	√	√	√	√	-		
		Electric power steering	-	-	-	-	-		
		Trailer relay unit	-	-	-	-	-		
		Telematics	√	√	√	√	-		
		Instrument panel	√	√	√	√	-		
		Radio	√	√	√	√	-		
		Anti-theft alarm	√	√	√	√	-		
		Driver and passenger airbags	√	√	√	√	-		
		Air conditioning	√	√	√	√	-		
	Air conditioning	√	√	√	√	-			
	Switch module under the steering wheel (Top of column)	√	√	√	√	-			
	Rain and brightness sensor (CDPL)	√	√	√	√	-			
	Services module	√	√	√	√	-			
Engine ECU		Built-in Systems Interface	√	√	√	√	-		
			MEV17_4_2	√	√	√	√	-	
			MEV17_4_EURO4	√	√	√	√	-	
			MEV17_4_EURO5					Initialising the autoadap tives	
			MED17_4_EURO4	√	√	√	√	-	
			EDC16C3	√	√	√	√	-	

C3 PICASSO		EDC17C10	✓	✓	✓	✓	✓	-		
		EDC17C10 BR2	✓	✓	✓	✓	✓	-		
		HDI_SID807	✓	✓	✓	✓	✓	-		
		HDI_SID807 BR2	✓	✓	✓	✓	✓	-		
	ABS/ESP		ABS MK70.2	✓	✓	✓	✓	✓	Bleeding	
			ESP MK60_0	✓	✓	✓	✓	✓	Bleeding	
			ABS MK100	✓	✓	✓	✓	✓	Bleeding	
			ESP MK100	✓	✓	✓	✓	✓	Bleeding	
	Gearbox	CFC300P	✓	✓	✓	✓	✓	-		
		Electric power steering	✓	✓	✓	✓	✓	-		
		Multiplexed additive pump	✓	✓	✓	✓	✓	-		
	Battery charge status unit		BECEB	✓	✓	✓	✓	-	-	
			BECEB GEN2	✓	✓	✓	✓	-	-	
		Engine relay unit	✓	✓	✓	✓	-	-		
		Trailer relay unit	✓	✓	✓	✓	-	-		
		Air bag	✓	✓	✓	✓	-	-		
		Switch module at the steering wheel	✓	✓	✓	✓	✓	-		
		Parking aid	✓	✓	✓	✓	-	-		
		Air conditioning ECU	✓	✓	✓	✓	✓	-		
	Multifunction display		Type "A" (segments) AVEC buttons	✓	✓	✓	✓	-	-	
			Type "A" (segments) SANS buttons	✓	✓	✓	✓	-	-	
			Type "C" (dot matrix)	✓	✓	✓	✓	-	-	
			Type "C colour" (dot matrix)	✓	✓	✓	✓	-	-	
		Instrument panel	✓	✓	✓	✓	✓	-		
	Radio		RD4	✓	✓	✓	✓	✓	-	
			RD45	✓	✓	✓	✓	✓	-	
	Telematics		RADIONAV_RNEGC	✓	✓	✓	✓	✓	-	
			RNEG2010	✓	✓	✓	✓	✓	-	
		Hands-free kit (Telephone)	✓	✓	✓	✓	✓	-		
		Alarm	✓	✓	✓	✓	✓	-		
		Driver's door module	✓	✓	✓	✓	✓	-		
		Seat belts not fastened LED unit	✓	✓	✓	✓	✓	-		
		Service module	✓	✓	✓	✓	✓	-		
		Rain sensor	✓	✓	✓	✓	-	-		
		High frequency receiver	✓	✓	✓	✓	-	-		
	C3 AIRCROSS	Injection	Petrol engine						Initiali sation of the autoadap tive values	
				N6A/N6B/NFU BOSCH ME749	✓	✓	✓	✓	✓	
				/N6B/NFU BOSCH ME749 B10F	✓	✓	✓	✓	✓	Initiali sation of the autoadap tive values
			BSI	✓	✓	✓	✓	-	-	
			Trailer relay unit	✓	✓	✓	✓	✓	-	
		Airbag	✓	✓	✓	✓	-	-		
ABS		ABS MK 70.2	✓	✓	✓	✓	-	-		
		Alarm	✓	✓	✓	✓	-	-		
Telematic		Entry-level radio navigation(RNEG 2004 ECO)	✓	✓	✓	✓	-	-		
		Rain sensor/Brightness	✓	✓	✓	-	-	-		
		Parking assistance	✓	✓	✓	✓	✓	-		
Radio		Radio post-equipment	✓	✓	✓	✓	-	-		
		Switch module under the steering wheel	✓	✓	✓	✓	-	-		
		Instrument panel	✓	✓	✓	✓	-	-		
		Auto gearbox AL4						Initiali sation of auto-adaptati on		
Gearbox ECU			✓	✓	✓	✓	✓	-		
	Air conditioning	✓	✓	✓	✓	-	-			
Services module	Stolen vehicle location control unit	✓	✓	✓	✓	-	-			
C3 PICASSO (Ai58)	Built-in Systems Interface (BSI)		-	-	-	-	-	-		
	Injection/ ignition	ME749	✓	✓	✓	✓	-	-		
		ME749_EC5	✓	✓	✓	✓	-	-		
		V34.4	✓	✓	✓	✓	-	-		
		V34.5	✓	✓	✓	✓	-	-		
	ABS/ASR	ABSMK70_1	✓	✓	✓	✓	-	-		
		ESPMK60_0	✓	✓	✓	✓	-	-		
	Gearbox		✓	✓	✓	✓	-	-		
		Electric power steering	-	-	-	-	-	-		
		Trailer relay unit	-	-	-	-	-	-		
	Telematics	✓	✓	✓	✓	-	-			
	Instrument panel	✓	✓	✓	✓	-	-			

C4

	Radio	✓	✓	✓	✓	-	-
	Anti-theft alarm	✓	✓	✓	✓	-	-
	Driver and passenger airbags	✓	✓	✓	✓	-	-
	Air conditioning	✓	✓	✓	✓	-	-
	Air conditioning	✓	✓	✓	✓	-	-
	Switch module under the steering wheel(Top of column)	✓	✓	✓	✓	-	-
	Rain and brightness sensor (CDPL)	✓	✓	✓	✓	-	-
	Services module	✓	✓	✓	✓	-	-
	Built-in Systems Interface	✓	✓	✓	✓	-	-
Engine ECU	HDI_SID803	✓	✓	✓	✓	-	-
	MM6LP	✓	✓	✓	✓	-	-
	MM6LPB	✓	✓	✓	✓	-	-
	MM6LPC	✓	✓	✓	✓	-	-
	ME745	✓	✓	✓	✓	-	-
	EDC16C3	✓	✓	✓	✓	-	-
	HDI_SID803A	✓	✓	✓	✓	-	-
	MED17_4 EURO4	✓	✓	✓	✓	-	-
	DCM3.4	✓	✓	✓	✓	-	-
	MEV17_4 EURO4	✓	✓	✓	✓	-	-
	ME749	✓	✓	✓	✓	-	-
	EDC15C2	✓	✓	✓	✓	-	-
	MM6KP	✓	✓	✓	✓	-	-
	DCM3.5	✓	✓	✓	✓	-	-
HDI_SID807_BR2	✓	✓	✓	✓	-	-	
ABS/ASR	ABS_8_BOSCH	✓	✓	✓	✓	-	-
	ESP_8_BOSCH	✓	✓	✓	✓	-	-
	ABS_81	✓	✓	✓	✓	-	-
	ESP_81	✓	✓	✓	✓	-	-
gearbox	BVA_AM6_AT6_EURO5	✓	✓	✓	✓	-	-
	BVA_AL4	✓	✓	✓	✓	-	-
	BVA_AM6	✓	✓	✓	✓	-	-
	CFC300P	✓	✓	✓	✓	-	-
	Driver and passenger airbags	✓	✓	✓	✓	-	-
	Automatic gearbox electric control	✓	✓	✓	✓	-	-
Power steering electric pump	GEP_1	✓	✓	✓	✓	-	-
	GEP_2	✓	✓	✓	✓	-	-
	Pneumatic suspension	✓	✓	✓	✓	-	-
	Diesel additive	✓	✓	✓	✓	-	-
	Diesel additive adding pump	✓	✓	✓	✓	-	-
	Under inflation detection	✓	✓	✓	✓	-	-
	Directional headlamps	✓	✓	✓	✓	-	-
Battery charge status unit	BECB	✓	-	-	✓	-	-
	BECB_GEN2	✓	-	-	✓	-	-
	Electric secondary brake	✓	✓	✓	✓	-	-
	Lane departure warning system	✓	✓	✓	✓	-	-
	Engine relay unit	✓	✓	✓	✓	-	-
	Trailer relay unit	✓	✓	✓	✓	-	-
	Multifunction display	✓	✓	✓	✓	-	-
	Windscreen wiper	✓	-	-	-	-	-
	Parking aid	✓	✓	✓	✓	-	-
	ECU at the top of the steering column	✓	✓	✓	✓	-	-
	heating/ventilation	✓	✓	✓	✓	-	-
	Instrument panel	✓	✓	✓	✓	-	-
	Remote Instrument Panel Unit	✓	✓	✓	✓	-	-
	audio amplifier	✓	✓	✓	-	-	-
	CD player	✓	✓	✓	-	-	-
Telematics	RADIONAV_RNEGC	✓	✓	✓	✓	-	-
	BOITIER_TELEMATIQUE	✓	✓	✓	-	-	-
	Radio or radiotelephone (radio part)	✓	✓	✓	✓	-	-
Hands-free kit (Telephone)	KML	✓	✓	✓	✓	-	-
	BOITIER_NOMADE	✓	✓	✓	✓	-	-
	Anti-theft alarm	✓	✓	✓	✓	-	-
	Driver's seat memorizing unit	✓	✓	✓	✓	-	-
	Passenger door electronics	✓	✓	✓	✓	-	-
	Driver's door electronics	✓	✓	✓	✓	-	-
	Light pack unit	✓	-	-	✓	-	-
	Rain and brightness sensor	✓	✓	✓	-	-	-
	Driving school module	✓	-	-	-	-	-
	High frequency receiver	✓	✓	✓	✓	-	-
Services module	BTA	✓	✓	✓	✓	-	-
	BLVV	✓	✓	✓	✓	-	-
	Built-in Systems Interface	✓	✓	✓	✓	-	-
	HDI_SID803	✓	✓	✓	✓	-	-
	MM6LP	✓	✓	✓	✓	-	-
	MM6LPB	✓	✓	✓	✓	-	-
	MM6LPC	✓	✓	✓	✓	-	-
	ME745	✓	✓	✓	✓	-	-
	EDC16C3	✓	✓	✓	✓	-	-

C4 SEDAD

Engine ECU	HDI_SID803A	✓	✓	✓	✓	-	-
	MED17_4_EURO4	✓	✓	✓	✓	-	-
	DCM3.4	✓	✓	✓	✓	-	-
	MEV17_4_EURO4	✓	✓	✓	✓	-	-
	ME749	✓	✓	✓	✓	-	-
	EDC15C2	✓	✓	✓	✓	-	-
	MM6KP	✓	✓	✓	✓	-	-
	DCM3.5	✓	✓	✓	✓	-	-
	HDI_SID807_BR2	✓	✓	✓	✓	-	-
	ABS/ASR	ABS_8_BOSCH	✓	✓	✓	✓	-
ESP_8_BOSCH		✓	✓	✓	✓	-	-
ABS_81		✓	✓	✓	✓	-	-
ESP_81		✓	✓	✓	✓	-	-
gearbox	BVA_AM6_AT6_EURO5	✓	✓	✓	✓	-	-
	BVA_AL4	✓	✓	✓	✓	-	-
	BVA_AM6	✓	✓	✓	✓	-	-
	CFC300P	✓	✓	✓	✓	-	-
Driver and passenger airbags		✓	✓	✓	✓	-	-
Automatic gearbox electric control		✓	✓	✓	✓	-	-
Power steering electric pump	GEP_1	✓	✓	✓	✓	-	-
	GEP_2	✓	✓	✓	✓	-	-
Pneumatic suspension		✓	✓	✓	✓	-	-
Diesel additive		✓	✓	✓	✓	-	-
Diesel additive adding pump		✓	✓	✓	✓	-	-
Under inflation detection		✓	✓	✓	✓	-	-
Directional headlamps		✓	✓	✓	✓	-	-
Battery charge status unit	BECEB	✓	-	-	✓	-	-
	BECEB_GEN2	✓	-	-	✓	-	-
Electric secondary brake		✓	✓	✓	✓	-	-
Lane departure warning system		✓	✓	✓	✓	-	-
Engine relay unit		✓	✓	✓	✓	-	-
Trailer relay unit		✓	✓	✓	✓	-	-
Multifunction display		✓	✓	✓	✓	-	-
Windscreen wiper		✓	-	-	-	-	-
Parking aid		✓	✓	✓	✓	-	-
ECU at the top of the steering column heating/ventilation		✓	✓	✓	✓	-	-
Instrument panel		✓	✓	✓	✓	-	-
Remote Instrument Panel Unit		✓	✓	✓	✓	-	-
audio amplifier		✓	✓	✓	-	-	-
CD player		✓	✓	✓	-	-	-
Telematics	RADIONAV_RNEGC	✓	✓	✓	-	-	-
	BOITIER_TELEMATIQUE	✓	✓	✓	-	-	-
Radio or radiotelephone (radio part)		✓	✓	✓	✓	-	-
Hands-free kit (Telephone)	KML	✓	✓	✓	✓	-	-
	BOITIER_NOMADE	✓	✓	✓	✓	-	-
Anti-theft alarm		✓	✓	✓	✓	-	-
Driver's seat memorizing unit		✓	✓	✓	✓	-	-
Passenger door electronics		✓	✓	✓	✓	-	-
Driver's door electronics		✓	✓	✓	✓	-	-
Light pack unit		✓	-	-	✓	-	-
Rain and brightness sensor		✓	✓	✓	-	-	-
Driving school module		✓	-	-	-	-	-
High frequency receiver		✓	✓	✓	✓	-	-
Services module	BTA	✓	✓	✓	✓	-	-
	BLVV	✓	✓	✓	✓	-	-
Built-in Systems Interface		✓	✓	✓	✓	-	-
Engine ECU	HDI_SID803	✓	✓	✓	✓	-	-
	MM6LP	✓	✓	✓	✓	-	-
	MM6LPB	✓	✓	✓	✓	-	-
	MM6LPC	✓	✓	✓	✓	-	-
	ME745	✓	✓	✓	✓	-	-
	EDC16C3	✓	✓	✓	✓	-	-
	HDI_SID803A	✓	✓	✓	✓	-	-
	MED17_4_EURO4	✓	✓	✓	✓	-	-
	DCM3.4	✓	✓	✓	✓	-	-
	MEV17_4_EURO4	✓	✓	✓	✓	-	-
	ME749	✓	✓	✓	✓	-	-
	EDC15C2	✓	✓	✓	✓	-	-
	MM6KP	✓	✓	✓	✓	-	-
	DCM3.5	✓	✓	✓	✓	-	-
	HDI_SID807_BR2	✓	✓	✓	✓	-	-
ABS/ASR	ABS_8_BOSCH	✓	✓	✓	✓	-	-
	ESP_8_BOSCH	✓	✓	✓	✓	-	-
	ABS_81	✓	✓	✓	✓	-	-
	ESP_81	✓	✓	✓	✓	-	-
gearbox	BVA_AM6_AT6_EURO5	✓	✓	✓	✓	-	-
	BVA_AL4	✓	✓	✓	✓	-	-

C4 PICASSO	gearbox	BVA AM6	✓	✓	✓	✓	-	-	
		CFC300P	✓	✓	✓	✓	-	-	
	Driver and passenger airbags		✓	✓	✓	✓	-	-	
	Automatic gearbox electric control		✓	✓	✓	✓	-	-	
	Power steering electric pump	GEP 1	✓	✓	✓	✓	-	-	
		GEP 2	✓	✓	✓	✓	-	-	
	Pneumatic suspension		✓	✓	✓	✓	-	-	
	Diesel additive		✓	✓	✓	✓	-	-	
	Diesel additive adding pump		✓	✓	✓	✓	-	-	
	Under inflation detection		✓	✓	✓	✓	-	-	
	Directional headlamps		✓	✓	✓	✓	-	-	
	Battery charge status unit	BECEB	✓	-	-	✓	-	-	
		BECEB GEN2	✓	-	-	✓	-	-	
	Electric secondary brake		✓	✓	✓	✓	-	-	
	Lane departure warning system		✓	✓	✓	✓	-	-	
	Engine relay unit		✓	✓	✓	✓	-	-	
	Trailer relay unit		✓	✓	✓	✓	-	-	
	Multifunction display		✓	✓	✓	✓	-	-	
	Windscreen wiper		✓	-	-	-	-	-	
	Parking aid		✓	✓	✓	✓	-	-	
	ECU at the top of the steering column heating/ventilation		✓	✓	✓	✓	-	-	
	Instrument panel		✓	✓	✓	✓	-	-	
	Remote Instrument Panel Unit		✓	✓	✓	✓	-	-	
	audio amplifier		✓	✓	✓	-	-	-	
	CD player		✓	✓	✓	-	-	-	
	Telematics	RADIONAV RNEGC	✓	✓	✓	✓	-	-	
		BOITIER TELEMATIQUE	✓	✓	✓	-	-	-	
	Radio or radiotelephone (radio part)		✓	✓	✓	✓	-	-	
	Hands-free kit (Telephone)	KML	✓	✓	✓	✓	-	-	
		BOITIER NOMADE	✓	✓	✓	✓	-	-	
	Anti-theft alarm		✓	✓	✓	✓	-	-	
	Driver's seat memorizing unit		✓	✓	✓	✓	-	-	
	Passenger door electronics		✓	✓	✓	✓	-	-	
	Driver's door electronics		✓	✓	✓	✓	-	-	
	Light pack unit		✓	-	-	✓	-	-	
	Rain and brightness sensor		✓	✓	✓	-	-	-	
	Driving school module		✓	-	-	-	-	-	
	High frequency receiver		✓	✓	✓	✓	-	-	
	Services module	BTA	✓	✓	✓	✓	-	-	
		BLVV	✓	✓	✓	✓	-	-	
	C4 Aircross	Built-in Systems Interface (BSI)		✓	✓	✓	✓	-	-
		Injection/ignition	MIVEC	✓	✓	✓	✓	-	-
			CMM 4A92	✓	✓	✓	✓	-	-
			HDI 4N13	✓	✓	✓	✓	-	-
			HDI SID807 J3J4	✓	✓	✓	✓	-	-
		Gearbox		✓	✓	✓	✓	-	-
		Rear final drive piloted clutch		✓	✓	✓	✓	-	-
ded anti-start / Hands free starting access electronic modul		✓	✓	✓	✓	-	-		
Driver and passenger airbags		✓	✓	✓	✓	-	-		
Anti-theft alarm		-	✓	✓	✓	-	-		
Starting authorisation ECU		✓	✓	✓	✓	-	-		
Calculateur stop and start		✓	✓	✓	✓	-	-		
Steering wheel angle sensor		✓	✓	✓	-	-	-		
Parking aid		✓	✓	✓	✓	-	-		
Instrument panel		✓	✓	✓	✓	-	-		
Heating/ventilation		✓	✓	✓	✓	-	-		
Directional headlamps		✓	✓	✓	✓	-	-		
Power steering		✓	✓	✓	✓	-	-		
Radio or radiotelephone (radio part)		✓	✓	✓	✓	-	-		
Navigation		✓	✓	✓	-	-	-		
ABS/ASR	ABS	✓	✓	✓	✓	-	-		
	ESP	✓	✓	✓	✓	-	-		
C4 Aircross	Built-in Systems Interface		✓	-	-	-	-		
	Engine ECU	MEV17_4_2	✓	✓	✓	✓	-	-	
		MED17_4_2	✓	✓	✓	✓	-	-	
		HDI_SID807_BR2	✓	✓	✓	✓	-	-	
		EDC17C10_BR2	✓	✓	✓	✓	-	-	
		DCM35_BR2	✓	✓	✓	✓	-	-	
		MEVD17_4_2	✓	✓	✓	✓	-	-	
	ABS/ASR	ME745	✓	✓	✓	✓	-	-	
		ABS81	✓	✓	✓	✓	-	-	
	Gearbox	ESP81	✓	✓	✓	✓	-	-	
BVA_AT8		✓	✓	✓	✓	-	-		
CFC300P		✓	✓	✓	✓	-	-		
BVA AM6_AT6_EURO5		✓	✓	✓	✓	-	-		
Power steering electric pump unit		✓	✓	✓	✓	-	-		
Multiplexed additive pump		✓	✓	✓	✓	-	-		

C4 (B7)

	Under inflation detection	✓	✓	✓	✓	-	-
	Discharge bulbs vertical and horizontal adjustment	✓	✓	✓	✓	-	-
	Battery charge status unit	✓	-	-	✓	-	-
	Electric secondary brake	✓	✓	✓	✓	-	-
	Lane departure warning system	✓	✓	✓	✓	-	-
	Trailer relay unit	✓	✓	✓	✓	-	-
	Engine relay unit	✓	✓	✓	✓	-	-
	Air bag	✓	✓	✓	✓	-	-
	Instrument panel	✓	✓	✓	✓	-	-
	Parking aid	✓	✓	✓	✓	-	-
	heating/ventilation	✓	✓	✓	✓	-	-
	Switch module under the steering wheel(Top of column)	✓	✓	✓	✓	-	-
Display	EMF A UDS	✓	✓	✓	-	-	-
	EMF C UDS	✓	✓	✓	-	-	-
	Radio	-	✓	✓	-	-	-
	audio amplifier	✓	✓	✓	✓	-	-
	Telematics	✓	✓	✓	✓	-	-
	Anti-theft alarm	✓	✓	✓	✓	-	-
	Driver's seat memorizing unit	✓	✓	✓	✓	-	-
	Driver's door module	✓	✓	✓	✓	-	-
Matrix screen integral to the instrument panel	Colour matrix screen	✓	✓	✓	-	-	-
	Monochrome matrix screen	✓	✓	✓	-	-	-
	Seat belts not fastened LED unit	✓	-	-	-	-	-
	Rain and brightness sensor	✓	✓	✓	✓	-	-
	Driving school module	✓	-	-	-	-	-
	Independent telematic unit (BTA)	✓	✓	✓	✓	-	-
	Multiplexed control panel	✓	✓	✓	✓	-	-
	Monitoring of the blind spot	✓	✓	✓	✓	-	-
	Steering wheel with integral controls (VCI)	✓	✓	✓	✓	-	-
	Supply protection and management unit	✓	-	-	✓	-	-
	Built-in Systems Interface	✓	-	-	-	-	-
Engine ECU	MEV17_4_2	✓	✓	✓	✓	-	-
	MED17_4_2	✓	✓	✓	✓	-	-
	HDI_SID807_BR2	✓	✓	✓	✓	-	-
	EDC17C10_BR2	✓	✓	✓	✓	-	-
	DCM35_BR2	✓	✓	✓	✓	-	-
	MEVD17_4_2	✓	✓	✓	✓	-	-
ABS/ASR	ME745	✓	✓	✓	✓	-	-
	ABS81	✓	✓	✓	✓	-	-
Gearbox	ESP81	✓	✓	✓	✓	-	-
	BVA_AT8	✓	✓	✓	✓	-	-
	CFC300P	✓	✓	✓	✓	-	-
	BVA AM6 AT6 EURO5	✓	✓	✓	✓	-	-
	Power steering electric pump unit	✓	✓	✓	✓	-	-
	Multiplexed additive pump	✓	✓	✓	✓	-	-
	Under inflation detection	✓	✓	✓	✓	-	-
	Discharge bulbs vertical and horizontal adjustment	✓	✓	✓	✓	-	-
	Battery charge status unit	✓	-	-	✓	-	-
	Electric secondary brake	✓	✓	✓	✓	-	-
	Lane departure warning system	✓	✓	✓	✓	-	-
	Trailer relay unit	✓	✓	✓	✓	-	-
	Engine relay unit	✓	✓	✓	✓	-	-
	Air bag	✓	✓	✓	✓	-	-
	Instrument panel	✓	✓	✓	✓	-	-
	Parking aid	✓	✓	✓	✓	-	-
	heating/ventilation	✓	✓	✓	✓	-	-
	Switch module under the steering wheel(Top of column)	✓	✓	✓	✓	-	-
Display	EMF A UDS	✓	✓	✓	-	-	-
	EMF C UDS	✓	✓	✓	-	-	-
	Radio	-	✓	✓	-	-	-
	audio amplifier	✓	✓	✓	✓	-	-
	Telematics	✓	✓	✓	✓	-	-
	Anti-theft alarm	✓	✓	✓	✓	-	-
	Driver's seat memorizing unit	✓	✓	✓	✓	-	-
	Driver's door module	✓	✓	✓	✓	-	-
Matrix screen integral to the instrument panel	Colour matrix screen	✓	✓	✓	-	-	-
	Monochrome matrix screen	✓	✓	✓	-	-	-
	Seat belts not fastened LED unit	✓	-	-	-	-	-
	Rain and brightness sensor	✓	✓	✓	✓	-	-
	Driving school module	✓	-	-	-	-	-
	Independent telematic unit (BTA)	✓	✓	✓	✓	-	-
	Multiplexed control panel	✓	✓	✓	✓	-	-
	Monitoring of the blind spot	✓	✓	✓	✓	-	-
	Steering wheel with integral controls (VCI)	✓	✓	✓	✓	-	-

C4 L (B7)

Injection		3.0XFX BOSCH ME746						Initiali sation of the autoadap tive values
		1.8L 6FZ SAGEM S2000P	√	√	√	√	√	-
		6FZ SAGEM 2000PM1	√	√	√	√	√	-
		2.0 RLZ SIEMENS Sirius81	√	√	√	√	√	-
	Diesel	RHY SIEMENS SID801						Initiali sation of the autoadap tive values
Anti-lock brake system		ABS	√	√	√	√	√	-
		ESP	√	√	√	√	√	-
Suspension		Suspension	√	√	√	√	√	-
		ECOTECH SUSPENSION	√	√	√	√	√	-
Auto gearbox		Auto gearbox AL4						Initiali sation of auto- adaptati on
		Auto gearbox 4HP20						Initiali sation of auto- adaptati on
		Additional heating	√	√	√	√	√	-
		Right-hand headlamp	√	√	√	√	√	-
		Left-hand headlamp	√	√	√	√	√	-
		Built-in Systems Interface	√	√	√	√	√	-
Engine ECU		MEV17_4_2						Initiali sing the autoadap tives
		MED17_4_2	√	√	√	√	√	Initiali sing the autoadap tives
		ME747						Initiali sing the autoadap tives
		SID201	√	√	√	√	√	-
		EDC16CP39	√	√	√	√	√	-
		MM6KP						Initiali sing the autoadap tives
		DCM3_4	√	√	√	√	√	-
		DCM3_4 P	√	√	√	√	√	-
		DCM3_5						Initiali sing the autoadap tives
		DCM3_5_BR2						Initiali sing the autoadap tives
		EDC16C3	√	√	√	√	√	-
		EDC17CP11	√	√	√	√	√	-
		MED17_4 EURO5	√	√	√	√	√	-
		HDI_SID807_BR2	√	√	√	√	√	-
		EDC17CP42	√	√	√	√	√	-
	HDI_SID807	√	√	√	√	√	-	
		ABS/traction control	√	√	√	√	√	Bleeding
Gearbox		BVA_AM6_AT6 EURO5	√	√	√	√	√	-
		BVA_AM6	√	√	√	√	√	-
		BVA_AL4						Initiali sing the autoadap tives
		CFC300P	√	√	√	√	√	-
		Power steering electric pump unit	√	√	√	√	√	-
		Electronically managed suspension	√	√	√	√	√	-
		BASHE 5	√	√	√	√	√	-

C5 (X7)

	CSS	✓	✓	✓	✓	✓	-
	Additional heating	✓	✓	✓	✓	-	-
	Under inflation detection	✓	✓	✓	✓	-	-
	Directional headlamps	✓	✓	✓	✓	✓	-
Battery charge status unit	BECB	✓	✓	✓	✓	-	-
	BECB_GEN2	✓	✓	✓	✓	-	-
	Electric secondary brake	✓	✓	✓	✓	✓	-
	Lane departure warning system	✓	✓	✓	✓	✓	-
	Trailer relay unit	✓	✓	✓	✓	-	-
	Engine relay unit	✓	✓	✓	✓	-	-
	Driver and passenger airbags	✓	✓	✓	✓	-	-
Multifunction screen(EMF)	Type "A" (segments) AVEC buttons	✓	✓	✓	✓	✓	-
	Type "A" (segments) SANS buttons	✓	✓	✓	✓	✓	-
	Type "C" (dot matrix)	✓	✓	✓	✓	✓	-
	Type "C colour" (dot matrix)	✓	✓	✓	✓	✓	-
	Windscreen wiper	✓	✓	✓	-	-	-
	Parking aid	✓	✓	✓	✓	-	-
	ECU at the top of the steering column heating/ventilation	✓	✓	✓	✓	✓	-
	Instrument panel	✓	✓	✓	✓	✓	-
	audio amplifier	✓	✓	✓	-	✓	-
	CD player	✓	✓	✓	-	✓	-
Hands-free kit (Telephone)	KML	✓	✓	✓	✓	✓	-
	BOITIER NOMADE	✓	✓	✓	✓	✓	-
Radio or radiotelephone	RD4	✓	✓	✓	✓	✓	-
	RD45	✓	✓	✓	✓	✓	-
Telematics	BOITIER TELEMATIQUE	✓	✓	✓	✓	✓	-
	RADIONAV_RNEG	✓	✓	✓	✓	✓	-
	RADIONAV_NG4	✓	✓	✓	✓	✓	-
	RADIONAV_RNEGC	✓	✓	✓	✓	✓	-
	Anti-theft alarm	✓	✓	✓	✓	✓	-
	Driver's seat memorizing unit	✓	✓	✓	✓	✓	-
	Driver's door module	✓	✓	✓	✓	✓	-
Service module	MD_SERV	✓	✓	✓	✓	✓	-
	BTA	✓	✓	✓	✓	✓	-
	Rain and brightness sensor	✓	✓	✓	-	-	-
	Seat belts not fastened LED unit	✓	✓	✓	-	✓	-
	Motorised Boot ECU	✓	✓	✓	✓	✓	-
	High frequency receiver	✓	✓	✓	✓	-	-
	Active damper electronic unit	✓	✓	✓	✓	-	-
	BSI	✓	✓	✓	✓	✓	-
	Instrument panel	✓	✓	✓	✓	-	-
Radio	Radio post-equipment	✓	✓	✓	✓	✓	-
	CD player	✓	✓	✓	✓	✓	-
	Parking assistance	✓	✓	✓	✓	✓	-
	Air conditioning	✓	✓	✓	✓	-	-
	Lane departure warning system	✓	✓	✓	✓	✓	-
	Alarm	✓	✓	✓	✓	✓	-
	Switch module under the steering wheel	✓	✓	✓	✓	✓	-
	Diesel additive function	ADDG03	✓	✓	✓	✓	-
	Driver's door module		✓	✓	✓	✓	-
	Passenger's door module		✓	✓	✓	✓	-
	Rain sensor/Brightness		✓	✓	✓	-	-
	Sun roof		✓	✓	✓	-	-
	Airbag		✓	✓	✓	-	-
Multifunction screen	Multifunction screen A	✓	✓	✓	✓	-	-
	Multifunction screen C	✓	✓	✓	✓	✓	-
Telematic	Telematics (RT3)	✓	✓	✓	✓	✓	-
	Telematics (RT4)	✓	✓	✓	✓	✓	-
	Telematics (RT5)	✓	✓	✓	✓	✓	-
Petrol engine	RFJ MM6LPB	✓	✓	✓	✓	✓	Initialisation of auto-adaptation
	6FY MM6LPB		✓	✓	✓	✓	Initialisation of auto-adaptation
	XFU BOSCH ME747	✓	✓	✓	✓	-	Initialisation of auto-adaptation

C5 R

							Initiali- sation of auto- adaptati- on
		XFV BOSCH ME747	✓	✓	✓	✓	-
		6FZ SAGEM S2000PM2	✓	✓	✓	✓	-
Diesel engine		4HP BOSCH EDC16CP39 DW12BTED4	✓	✓	✓	✓	Specific operatio- ns for maintena- nce for part replacem- ent
		4HR BOSCH EDC16CP39 DW12BTED4	✓	✓	✓	✓	Specific operatio- ns for maintena- nce for part replacem- ent
		4HS BOSCH EDC16CP39 DW12BTED4	✓	✓	✓	✓	Specific operatio- ns for maintena- nce for part replacem- ent
		4HT BOSCH EDC16CP39 DW12BTED4	✓	✓	✓	✓	Specific operatio- ns for maintena- nce for part replacem- ent
		2.2L 4HX BOSCH EDC15C2	✓	✓	✓	✓	-
		9HY BOSCH EDC16CP34 DV6TED4	✓	✓	✓	✓	Specific operatio- n for maintena- nce and part replacem- ent
		9HZ(FAP) BOSCH EDC16C34 DV6ATED4	✓	✓	✓	✓	Specific operatio- n for maintena- nce and part replacem- ent
		RHR SIEMENS SID803A	✓	✓	✓	✓	Specific operatio- n for maintena- nce and part replacem- ent
		RHL SIEMENS SID803A	✓	✓	✓	✓	Specific operatio- n for maintena- nce and part replacem- ent

	RHR SIEMENS SID803	✓	✓	✓	✓	-	Specific operation for maintenance and part replacement
	RHL SIEMENS SID803	✓	✓	✓	✓	-	Specific operation for maintenance and part replacement
	Trailer relay unit	✓	✓	✓	✓	✓	-
	Engine relay unit	✓	✓	✓	✓	✓	-
	Anti-lock brake system	✓	✓	✓	✓	-	-
	Suspension	✓	✓	✓	✓	✓	-
	Gearbox ECU	✓	✓	✓	✓	✓	Initialisation of auto-adaptation
	Additional heating	✓	✓	✓	✓	✓	-
	Power steering	✓	✓	✓	✓	✓	-
	Directional headlamps	✓	✓	✓	-	✓	-
	Deflation detection	✓	✓	✓	✓	✓	-
	Hands Free Kit	✓	✓	✓	✓	✓	-
	Built-in Systems Interface	✓	✓	✓	✓	-	-
Engine ECU	ME747	✓	✓	✓	✓	✓	Initialising the autoadaptatives
	SID201	✓	✓	✓	✓	✓	-
	EDC16CP39	✓	✓	✓	✓	✓	-
	EDC17CP11	✓	✓	✓	✓	✓	-
ABS/traction control	ESP_EBC_440_CAN	✓	✓	✓	✓	✓	-
	ESP_EBC_440_K	✓	✓	✓	✓	✓	-
	ESP	✓	✓	✓	✓	✓	Bleeding
Gearbox	BVA_AM6_AT6_EURO5	✓	✓	✓	✓	✓	-
	BVA_AM6	✓	✓	✓	✓	✓	-
	Power steering electric pump unit	✓	✓	✓	✓	✓	-
	Electronically managed suspension	✓	✓	✓	✓	✓	-
	CSS	✓	✓	✓	✓	✓	-
	Additional heating	✓	✓	✓	✓	-	-
	Under inflation detection	✓	✓	✓	✓	-	-
	Directional headlamps	✓	✓	✓	✓	✓	-
	Right headlamp beam corrector	✓	✓	✓	✓	-	-
	Left headlamp beam level corrector	✓	✓	✓	✓	-	-
Battery charge status unit	BECEB	✓	✓	✓	✓	-	-
	BECEB GEN2	✓	✓	✓	✓	-	-
	Electric secondary brake	✓	✓	✓	✓	✓	-
	Lane departure warning system	✓	✓	✓	✓	✓	-
	Boot wiring housing	✓	✓	✓	✓	-	-
	Engine relay unit	✓	✓	✓	✓	✓	-
	Trailer relay unit	✓	✓	✓	✓	✓	-
	Driver and passenger airbags	✓	✓	✓	✓	-	-
	Instrument panel	✓	✓	✓	✓	✓	-
Multifunction display	Type "A" (segments) AVEC buttons	✓	✓	✓	✓	✓	-
	Type "A" (segments) SANS buttons	✓	✓	✓	✓	✓	-
	Type "C" (dot matrix)	✓	✓	✓	✓	✓	-
	Type "C colour" (dot matrix)	✓	✓	✓	✓	✓	-
	Windscreen wiper	✓	✓	✓	-	-	-
	Parking aid	✓	✓	✓	✓	-	-
	Switch module under the steering wheel(Top of column) heating/ventilation	✓	✓	✓	✓	✓	-
Hands-free kit (Telephone)	KML	✓	✓	✓	✓	✓	-
	BOITIER NOMADE	✓	✓	✓	✓	✓	-
	Radio or radiotelephone (radio part)	✓	✓	✓	✓	✓	-
	Telematics	✓	✓	✓	✓	✓	-
	CD player	✓	✓	✓	✓	✓	-
	Anti-theft alarm	✓	✓	✓	✓	✓	-
	Rear seat memorising unit	✓	✓	✓	✓	✓	-
	Passenger seat memorisation unit	✓	✓	✓	✓	✓	-
	Driver's seat memorizing unit	✓	✓	✓	✓	✓	-
	Passenger door electronics	✓	✓	✓	✓	✓	-

C6

	Driver's seat panel	✓	✓	✓	✓	✓	-		
	Passenger's seat panel	✓	✓	✓	✓	✓	-		
	Driver's door electronics	✓	✓	✓	✓	✓	-		
	Moving panel deflector	✓	✓	✓	✓	✓	-		
CDSP (Dynamic Headlamp)	CDSPD	✓	-	-	✓	-	-		
	CDSPG	✓	-	-	✓	-	-		
	Rear air conditioning table	✓	✓	✓	✓	✓	-		
	High Head Vision	✓	✓	✓	✓	✓	-		
	Rain and brightness sensor	✓	✓	✓			-		
	Pedestrian impact detection unit	✓	✓	✓	✓	✓	-		
	High frequency receiver	✓	✓	✓	✓	-	-		
C8 (Before 14 October 2005)	BSI	✓	✓	✓	✓	-	-		
	Instrument panel	✓	✓	✓	✓	✓	-		
	Radio or telematic receiver command	✓	✓	✓	✓	✓	-		
	CD player	✓	✓	✓	✓	✓	-		
	Parking assistance	✓	✓	✓	✓	✓	-		
	Air conditioning	✓	✓	✓	✓	-	-		
	LEDs and odometer ECU	✓	✓	✓	-	-	-		
	Memory unit	✓	✓	✓	✓	-	-		
	Rear sunroof	✓	✓	✓	✓	-	-		
	Front sunroof	✓	✓	✓	✓	-	-		
	Middle sunroof	✓	✓	✓	✓	-	-		
	Alarm	✓	✓	✓	✓	✓	-		
	Switch module at the steering wheel	✓	✓	✓	✓	✓	-		
	Sliding side doors module	✓	✓	✓	✓	-	-		
	Driver's door module	✓	-	✓	✓	✓	-		
	Passenger's door module	✓	✓	-	✓	✓	-		
	Diesel additive function	✓	-	✓	✓	✓	-		
	Airbag	✓	-	-	✓	-	-		
	Display or Telematics	✓	✓	-	✓	✓	-		
	Injection	Petrol engine	2.0L RFN MM48P	✓	✓	✓	✓	✓	Initiali sation of the autoadap tive values
			3FZ MM4MP2	✓	✓	✓	✓	✓	Initiali sation of auto- adaptati on
			RFN MM4MP2	✓	✓	✓	✓	✓	Initiali sation of auto- adaptati on
			RFN MM6LP	✓	✓	✓	✓	✓	Initiali sation of the autoadap tive values
			3FZ MM6LP	✓	✓	✓	✓	✓	Initiali sation of the autoadap tive values
			3.0L XFW BOSCH ME746	✓	✓	✓	✓	✓	Initiali sation of the autoadap tive values
			ABR5.3	✓	✓	✓	✓	-	-
	Anti-lock brake system	ESP BOSCH5.7	✓	✓	✓	✓	✓	ESP Calibrat ion	
	Auto gearbox	Auto gearbox AL4	✓	✓	✓	✓	✓	-	
		Auto gearbox 4HP20	✓	✓	✓	✓	✓	-	
		Additional heating	✓	✓	✓	✓	✓	-	
	Right-hand headlamp	✓	✓	✓	✓	-	-		
	Left-hand headlamp	✓	✓	✓	✓	-	-		
	Built-in Systems Interface	✓	✓	✓	✓		Maintena nce-BSI operatin g mode		
	EDC15C2	✓	✓	✓	✓	✓			

C8(After 14
October
2005)

Engine ECU	MM6LPB	✓	✓	✓	✓	✓	Initialising the autoadaptive values
	HDI_SID803A	✓	✓	✓	✓	✓	-
	EDC16CP39	✓	✓	✓	✓	✓	-
	DCM3.5	✓	✓	✓	✓	✓	Initialisation of the autoadaptive values
ABS/traction control	ESP8 BOSCH	✓	✓	✓	✓	✓	-
	ESP 81	✓	✓	✓	✓	✓	Bleeding
Gearbox	BVA AM6	✓	✓	✓	✓	✓	-
	BVA AL4	✓	✓	✓	✓	✓	Initialising the autoadaptive values
	BVA AM6 AT6 EURO5	✓	✓	✓	✓	✓	-
Power steering electric pump unit		✓	✓	✓	✓	✓	-
Diesel additive		✓	✓	✓	✓	✓	-
Additional heating		✓	✓	✓	✓	-	-
Under inflation detection		✓	✓	✓	✓	-	-
Left headlamp beam level corrector		✓	✓	✓	✓	-	-
Right headlamp beam corrector		✓	✓	✓	✓	-	-
Trailer relay unit		✓	✓	✓	✓	-	-
Engine relay unit		✓	✓	✓	✓	-	-
Driver and passenger airbags		✓	✓	✓	✓	-	-
Multifunction screen (EMF)	Type "A" (segments) AVEC buttons	✓	✓	✓	✓	✓	-
	Type "A" (segments) SANS buttons	✓	✓	✓	✓	✓	-
	Type "C" (dot matrix)	✓	✓	✓	✓	✓	-
	Type "C colour" (dot matrix)	✓	✓	✓	✓	✓	-
heating/ventilation		✓	✓	✓	✓	✓	-
Instrument panel		✓	✓	✓	✓	✓	-
Switch module under the steering wheel (Top of column)		✓	✓	✓	✓	✓	-
Parking aid		✓	✓	✓	✓	-	-
CD player		✓	✓	✓	✓	✓	-
Radio	RD4	✓	✓	✓	✓	✓	-
	RD45	✓	✓	✓	✓	✓	-
Hands-free kit (Telephone)	KML	✓	✓	✓	✓	✓	-
	BOITIER NOMADE	✓	✓	✓	✓	✓	-
Telematic	RADIONAV TELEMATIQUE	✓	✓	✓	✓	✓	-
	RADIONAV RNEG	✓	✓	✓	✓	✓	-
	RNEG2010s	✓	✓	✓	✓	✓	-
Driver's seat memorizing unit		✓	✓	✓	✓	✓	-
Anti-theft alarm		✓	✓	✓	✓	✓	-
Passenger door electronics		✓	✓	✓	✓	✓	-
Sliding side door modules (left-hand or only)		✓	✓	✓	✓	✓	-
Driver's door electronics		✓	✓	✓	✓	✓	-
Rear sunroof		✓	✓	✓	✓	✓	-
Front sunroof		✓	✓	✓	✓	✓	-
Middle sunroof		✓	✓	✓	✓	✓	-
Odometer Warning Lights unit		✓	✓	✓	✓	✓	-
Rain and brightness sensor		✓	✓	✓	-	-	-
Telematic receiver control		✓	-	-	✓	-	-
Built-in Systems Interface		✓	✓	✓	✓	-	-
Engine ECU	EDC16CP39	✓	✓	✓	✓	✓	-
	EDC16CP39 E5	✓	✓	✓	✓	✓	-
	MIVEC	✓	✓	✓	✓	✓	-
ABS/traction control	ABS	✓	✓	✓	✓	-	-
	ESP	✓	✓	✓	✓	-	-
Gearbox	BV_CVT	✓	✓	✓	✓	-	-
	BOITE GETRAG	✓	✓	✓	✓	-	-
Gear lever		✓	✓	✓	✓	-	-
Rear final drive piloted clutch		✓	✓	✓	✓	-	-
Locking and immobiliser control module		✓	✓	✓	✓	-	-
Driver and passenger airbags		✓	✓	✓	✓	-	-
Instrument panel		✓	✓	✓	✓	-	-
heating/ventilation		✓	✓	✓	✓	-	-
Hands-free kit (Telephone)		✓	✓	✓	✓	-	-
Navigation		✓	✓	✓	✓	-	-

C-CROSSER

		Radio or radiotelephone (radio part)	✓	✓	✓	✓	-	-	
		Rear LH door switch panel	✓	✓	✓	✓	-	-	
		Driver's door module	✓	✓	✓	✓	-	-	
		Passenger door module	✓	✓	✓	✓	-	-	
		Rear RH door switch panel	✓	✓	✓	✓	-	-	
		Sun roof	✓	✓	✓	✓	-	-	
		Steering wheel angle sensor	✓	✓	✓	✓	-	-	
		Rain and brightness sensor	✓	✓	✓	✓	-	-	
		Parking aid	✓	✓	✓	✓	-	-	
		Directional headlamps	✓	✓	✓	✓	-	-	
		BSI	-	✓	✓	-	-	-	
NEMO	Injection/ Ignition	Petrol engine	KFV V34P	✓	✓	✓	-	-	
			KFT V34.2	✓	-	✓	-	-	
	Diesel engine	8 HS BOSCH EDC16C34	✓	✓	-	-	-		
		HDI 8DF2	✓	✓	✓	-	-		
	Gearbox	Gearbox BVMP MAP	Controlled manual gearbox MTA	✓	✓	✓	-	-	
			Controlled manual gearbox MTA	✓	✓	✓	-	-	
	Anti-lock Brake system/ Electronic stability program	ABS	ESP 8.1	✓	✓	✓	-	-	
			ESP 8.1	✓	✓	✓	-	-	
	Driver's and passenger's airbags			✓	✓	✓	-	-	
	Instrument panel			✓	✓	✓	-	-	
Parking assistance			✓	✓	✓	-	-		
BERLINGO (Before 4 June 2000)	Electrical vehicle			✓	✓	✓	-	-	
	Injection	Petrol engine	1. 1L HDY/HDZ BOSCH MA3.1	✓	✓	✓	✓	-	-
			1. 4L KFX SAGEM SL96	✓	✓	✓	✓	-	-
			1. 4L KFX MMIAP	-	✓	✓	-	-	-
			1. 4L KFX BOSCH MP7.3	✓	✓	✓	✓	✓	-
			1. 8L LFX MMIAP	✓	✓	✓	✓	✓	-
	Diesel engine	2. 0L RHY BOSCH EDC15C2	✓	✓	✓	✓	✓	-	
	Additional heating			✓	✓	✓	✓	✓	
	Anti-lock brake system	ABS		✓	-	✓	✓	-	
		ABS electronic distribution		✓	✓	-	✓	-	
	Airbag	Airbag TRW		✓	✓	✓	-	-	
		Airbag AUTOLIV		-	✓	✓	-	-	
	Transponder			✓	✓	✓	✓	-	
	Coded immobiliser			✓	✓	✓	✓	-	
BERLINGO (After 4 June 2000)	BSI			✓	✓	✓	✓	-	
	Radio post-equipment			✓	✓	✓	✓	✓	
	CD player			✓	✓	✓	✓	✓	
	Instrument panel			✓	✓	✓	-	-	
	Electrical vehicle			✓	✓	✓	-	-	
	Injection	Petrol engine	1. 1L HDY/HDZ BOSCH MA3.1	✓	-	✓	✓	-	-
			1. 1L HFX BOSCH M7.4.4	✓	✓	-	✓	✓	-
			1. 4L KFW SAGEM S2000	✓	✓	✓	✓	✓	-
			1. 4L KFW SAGEM S2000	✓	✓	✓	✓	✓	-
			1. 4L KFX SAGEM SL96	✓	✓	✓	✓	✓	-
			1. 4L KFX BOSCH MP7.3	✓	✓	✓	✓	✓	-
		Diesel engine	1. 6L NFU BOSCH ME7.4.4	✓	✓	✓	✓	✓	Initiali sation of auto- adaptati on
			1. 8L LFX MMIAP	-	✓	✓	-	-	-
			2. 0L RHY BOSCH EDC15C2	✓	✓	✓	✓	✓	-
			1. 9L WJY LUCAS DCN2 RHY SIEMENS SID801	✓	-	✓	✓	-	-
	Additional heating			✓	✓	-	✓	✓	
	Anti-lock brake system			✓	✓	✓	✓	-	
	Airbag	Airbag TRW		✓	✓	✓	-	-	
		Airbag AUTOLIV		-	✓	✓	-	-	
		BSI			✓	✓	✓	✓	-
Instrument panel			✓	✓	✓	✓	✓		
Radio post-equipment		Radio post-equipment		✓	✓	✓	✓	✓	
		Radio post-equipment RDE Wire		✓	✓	✓	✓	-	
CD player			✓	✓	✓	✓	✓		
Parking assistance			✓	✓	✓	✓	✓		
Alarm			✓	✓	✓	-	✓		
Switch module at the steering wheel			✓	-	✓	✓	-		
Rain sensor/Brightness			✓	-	-	-	-		
Airbag			✓	-	-	-	-		
Display or Telematics		Multifunction display SAGEM A		✓	-	-	✓	✓	
		Multifunction display SAGEM B		✓	✓	-	✓	✓	
		Telematics unit		✓	✓	✓	✓	✓	
			TU3A J34P	✓	✓	✓	-	✓	

BERLINGO 2	Injection	Petrol engine	2.0l RFN MM48P	✓	✓	✓	✓	✓	Initialisation of the autoadaptive values
			NFU BOSCH ME744	✓	✓	✓	✓	✓	Initialisation of autoadaptation
			KFV SAGEM S2000PM1	✓	✓	✓	✓	✓	-
			KFW SAGEM S2000PM1	✓	✓	✓	✓	✓	-
			KFV SAGEM S2000PM2	✓	✓	✓	✓	-	-
			KFW SAGEM S2000PM2	✓	✓	✓	✓	-	-
			NFS BOSCH ME745	✓	✓	✓	✓	✓	Initialise autoadaptive s
			NFU BOSCH ME745	✓	✓	✓	✓	✓	Initialise autoadaptive s
			N6A BOSCH ME745	✓	✓	✓	✓	✓	Initialise autoadaptive s
			NFR BOSCH ME745	✓	✓	✓	✓	-	Initialise autoadaptive s
			(N6A/N6B/NFU) BOSCH ME749	✓	✓	✓	✓	✓	Initialise autoadaptive s
		(N6B/NFU) BOSCH ME749 Bio	✓	✓	✓	✓	✓	Initialise autoadaptive s	
		Diesel engine	HX BOSCH EDC16C34 DV6ATED	✓	✓	✓	✓	-	Specific operation for maintenance and part replacement
			9HW BOSCH EDC16C34 DV6B	✓	✓	✓	✓	✓	Specific operation for maintenance and part replacement
			RHY SIEMENS SID801	✓	✓	✓	✓	✓	-
			WJY DCN2	✓	✓	✓	✓	✓	-
			EDC17C10_BR2-DV6DTEDM-92	✓	✓	✓	✓	-	Particulate filter after sales operation
			EDC17C10_BR2-DV6ETEDM-75	✓	✓	✓	✓	-	Particulate filter after sales operation
			E EDC17C10_BR2-DV6DBM-89	✓	✓	✓	✓	-	Particulate filter after sales operation

Gas injection	SAX500_GPL	✓	✓	✓	✓	-	-
	SAX500_GNV	✓	✓	✓	✓	-	-
Anti-lock brake system	ABS8.1_BOSCH	✓	✓	✓	✓	-	-
	ABS8_BOSCH	✓	✓	✓	✓	✓	-
	ABR5.5	✓	✓	✓	✓	-	-
	ESP8.1_BOSCH	✓	✓	✓	✓	-	ESP Calibration
	ESP_BOSCH5.7	✓	✓	✓	✓	✓	ESP Calibration
	ESP8_BOSCH	✓	✓	✓	✓	✓	ESP Calibration
additional heating		✓	✓	✓	✓	✓	-
Service module	Stolen vehicle location control unit	✓	✓	✓	✓	-	-
Built-in Systems Interface		✓	✓	✓	✓	-	-
Engine ECU	MEV17_4_2	✓	✓	✓	✓	✓	Initialising the autoadap tives
	ME745	✓	✓	✓	✓	✓	Initialising the autoadap tives
	EDC16C3	✓	✓	✓	✓	✓	-
	EDC17C10_BR2	✓	✓	✓	✓	✓	Initialising the autoadap tives
	HDI_SID807_BR2	✓	✓	✓	✓	✓	Initialising the autoadap tives
ABS/ASR	HDI_SID807	✓	✓	✓	✓	✓	-
	ABS81	✓	✓	✓	✓	✓	Bleeding
Gearbox	ESP81	✓	✓	✓	✓	✓	Bleeding
	ESP81	✓	✓	✓	✓	✓	-
Power steering electric pump unit		✓	✓	✓	✓	✓	-
Multiplexed additive pump	PADDGO	✓	✓	✓	✓	✓	-
	POMPE_MUX_TI	✓	✓	✓	✓	✓	-
Deflation detection		✓	✓	✓	✓	-	-
Battery charge status unit	BECEB	✓	✓	✓	✓	-	-
	BECEB_GEN2	✓	✓	✓	✓	-	-
Engine relay unit		✓	✓	✓	✓	-	-
Bodywork conversion unit		✓	✓	✓	✓	-	-
Trailer relay unit		✓	✓	✓	✓	-	-
Air bag		✓	✓	✓	✓	-	-
Air conditioning ECU	CLIM_REGULEE	✓	✓	✓	✓	✓	-
	CLIM	✓	✓	✓	✓	✓	-
Multifunction display	Type "A" (segments) AVEC buttons	✓	✓	✓	✓	✓	-
	Type "A" (segments) SANS buttons	✓	✓	✓	✓	✓	-
	Type "C" (dot matrix)	✓	✓	✓	✓	✓	-
	Type "C colour" (dot matrix)	✓	✓	✓	✓	✓	-
Instrument panel		✓	✓	✓	✓	✓	-
Parking aid		✓	✓	✓	✓	-	-
Switch module under the steering wheel(Top of column)		✓	✓	✓	✓	✓	-
Hands-free kit (Telephone)	KML	✓	✓	✓	✓	✓	-
	BOITIER_NOMADE	✓	✓	✓	✓	✓	-
Radio	RD4	✓	✓	✓	✓	✓	-
	RD45	✓	✓	✓	✓	✓	-
Telematics	RADIONAV_RNEGC	✓	✓	✓	✓	✓	-
	RNEG2010	✓	✓	✓	✓	✓	-
CD player		✓	✓	✓	✓	-	-
Alarm		✓	✓	✓	✓	✓	-
Anti-slip mode selector		✓	✓	✓	✓	-	-
Service module		✓	✓	✓	✓	✓	-
Rain sensor		✓	✓	✓	✓	-	-
High frequency receiver		✓	✓	✓	✓	-	-
Built-in Systems Interface		✓	✓	✓	✓	-	-
Radio	ABS/ASR	✓	✓	✓	✓	✓	Bleeding
	RD4	✓	✓	✓	✓	✓	-
	RD45	✓	✓	✓	✓	✓	-
Parking aid		✓	✓	✓	✓	-	-
Onboard charger of the traction battery		✓	✓	✓	✓	-	-
Traction battery ECU		✓	✓	✓	✓	-	-
Air conditioning ECU	CLIM_REGULEE	✓	✓	✓	✓	✓	-
	CLIM	✓	✓	✓	✓	✓	-

BERLINGO (B9)

BERLINGO Electric (B9e)	Instrument panel			✓	✓	✓	✓	✓	-	
	Passenger compartment air heating resistor			✓	✓	✓	✓	-	-	
	air conditioning compressor			✓	✓	✓	✓	-	-	
	Electric vehicle management ECU			✓	✓	✓	-	-	-	
	Service module			✓	✓	✓	✓	✓	-	
	Multifunction display	Type "A" (segments) AVEC buttons		✓	✓	✓	✓	✓	-	
		Type "A" (segments) SANS buttons		✓	✓	✓	✓	✓	-	
		Type "C" (dot matrix)		✓	✓	✓	✓	✓	-	
		Type "C colour" (dot matrix)		✓	✓	✓	✓	✓	-	
	Drive train interface ECU			✓	-	-	-	-	-	
	Alarm			✓	✓	✓	✓	✓	-	
	Air bag			✓	✓	✓	✓	-	-	
	Rain sensor			✓	✓	✓	-	-	-	
	Power steering electric pump unit			✓	✓	✓	✓	✓	-	
	Telematics	RADIONAV RNEGC		✓	✓	✓	✓	✓	-	
		RNEG2010		✓	✓	✓	✓	✓	-	
	Electric machine management ECU			✓	✓	✓	✓	-	-	
Engine relay unit			✓	✓	✓	✓	-	-		
Switch module under the steering wheel(Top of column)			✓	✓	✓	✓	✓	-		
JUMPY	Codeed anti-theft device			✓	✓	✓	✓	-	-	
	Injection	Petrol engine	2.0L RFN MM48P	✓	✓	✓	✓	✓	Initiali sation of the autoadap tive values	
			1.9L DHX BOSCH AS3-VP20	✓	✓	✓	✓	-	-	
	Diesel engine	2.0L RHW BOSCH EDC15C2	✓	✓	✓	✓	✓	-		
		2.0L RHZ BOSCH EDC15C2	✓	✓	✓	✓	✓	-		
		2.0L RHX BOSCH EDC15C2	✓	-	✓	✓	✓	-		
		1.9L WJY LUCAS DCN2	✓	-	-	✓	✓	-		
	Anti-lock brake system			✓	-	-	✓	-	-	
	Auto gearbox			✓	✓	-	✓	✓	-	
	Additional heating			✓	✓	✓	✓	✓	-	
Airbag			✓	✓	✓	-	-	-		
CPH			✓	✓	✓	✓	-	-		
JUMPY 2	Injection	Petrol engine	2.0L RFN MM48P	✓	✓	✓	✓	✓	Initiali sation of the autoadap tive values	
			2.0L RHW BOSCH EDC15C2	✓	-	✓	✓	✓	-	
	Diesel engine	2.0L RHZ BOSCH EDC15C2	✓	✓	-	✓	✓	-		
		2.0L RHX BOSCH EDC15C2	✓	-	✓	✓	✓	-		
		1.9L WJY LUCAS DCN2	✓	-	-	✓	✓	-		
	Anti-lock brake system			✓	-	-	✓	-	-	
	Auto gearbox			✓	✓	-	✓	✓	-	
	additional heating			✓	✓	✓	✓	✓	-	
Airbag			✓	✓	✓	-	-	-		
CPH			✓	✓	✓	✓	-	-		
Engine ECU	Built-in Systems Interface			✓	✓	✓	✓	-	-	
	Engine ECU	EDC16C3		✓	✓	✓	✓	✓	-	Initiali sation of the autoadap tive values
		EDC17C10 BR2		✓	✓	✓	✓	✓	-	Initiali sing the autoadap tives
		HDI SID803A		✓	✓	✓	✓	✓	-	Initiali sing the autoadap tives
		MM6KP		✓	✓	✓	✓	✓	-	Initiali sing the autoadap tives
		DCM3.5		✓	✓	✓	✓	✓	-	Initiali sing the autoadap tives
		DCM3.5 BR2		✓	✓	✓	✓	✓	-	Initiali sing the autoadap tives
		DCM3.5 BR2		✓	✓	✓	✓	✓	-	Initiali sing the autoadap tives
	ABS/ASR	ABS 81		✓	✓	✓	✓	✓	-	Bleeding
		ESP 81		✓	✓	✓	✓	✓	-	Bleeding
		ABS 8_BOSCH		✓	✓	✓	✓	✓	-	-
		ESP 8_BOSCH		✓	✓	✓	✓	✓	-	-
Gearbox			✓	✓	✓	✓	✓	-	-	
Power steering electric pump unit			✓	✓	✓	✓	✓	-	-	

JUMPY 3	Deflation detection (DSG)		✓	✓	✓	✓	-	-	
	Pneumatic suspension		✓	✓	✓	✓	✓	-	
	Additional heating		✓	✓	✓	✓	-	-	
	Trailer relay unit		✓	✓	✓	✓	-	-	
	Bodywork conversion unit		✓	✓	✓	✓	-	-	
	Engine relay unit		✓	✓	✓	✓	-	-	
	Driver and passenger airbags		✓	✓	✓	✓	-	-	
	Instrument panel		✓	✓	✓	✓	✓	-	
	Parking aid		✓	✓	✓	✓	-	-	
	Switch module under the steering wheel(Top of column)		✓	✓	✓	✓	✓	-	
	Multifunction display	Type "A" (segments) AVEC buttons		✓	✓	✓	✓	✓	-
		Type "A" (segments) SANS buttons		✓	✓	✓	✓	✓	-
		Type "C" (dot matrix)		✓	✓	✓	✓	✓	-
		Type "C colour" (dot matrix)		✓	✓	✓	✓	✓	-
	heating/ventilation		✓	✓	✓	✓	✓	-	
	CD player		✓	✓	✓	-	✓	-	
	Hands-free kit (Telephone)	KML		✓	✓	✓	✓	✓	-
		BOITIER NOMADE		✓	✓	✓	✓	✓	-
	Radio	RD4		✓	✓	✓	✓	✓	-
		RD45		✓	✓	✓	✓	✓	-
	Telematics	RADIONAV TELEMATIQUE		✓	✓	✓	✓	✓	-
		RADIONAV RNEG		✓	✓	✓	✓	✓	-
		RNEG2010		✓	✓	✓	✓	✓	-
	Anti-theft alarm		✓	✓	✓	✓	✓	-	
	Anti-slip mode selector		✓	-	-	✓	-	-	
	Rear air conditioning table		✓	✓	✓	✓	✓	-	
	Rain and brightness sensor		✓	✓	✓	-	-	-	
High frequency receiver		✓	✓	✓	✓	-	-		
Battery charge status unit		✓	✓	✓	✓	-	-		
JUMPER	Injection	Petrol engine						Initialisation of the autoadaptive values	
			2.0 L RFL MM48P	✓	✓	✓	✓		✓
	Diesel engine		2.8 L BOSCH EDC15C7	-	✓	✓	✓	-	-
			RHV BOSCH EDC15C7	-	✓	✓	✓	-	-
		4HY L BOSCH EDC15C7	-	✓	✓	✓	-	-	
JUMPER 2	Injection	Petrol engine						Initialisation of the autoadaptive values	
			2.0L RFW MM48P	✓	✓	✓	✓		✓
	Diesel engine		EDC16C39 SOFIM 2.3	✓	✓	✓	✓	-	-
			2.8 L BOSCH EDC15C7	-	✓	✓	✓	-	-
			RHV BOSCH EDC15C7	-	✓	✓	✓	-	-
			4HY BOSCH EDC15C7	-	✓	✓	✓	-	-
	Auto gearbox		✓	✓	✓	✓	-	-	
Additional heating		✓	✓	✓	✓	-	-		
Service module		✓	✓	✓	✓	-	-		
Immobiliser control module		✓	✓	✓	✓	-	-		
JUMPER 3	Instrument panel		✓	-	✓	✓	-	-	
	Parking assistance		✓	-	-	✓	-	-	
	Telematic		✓	✓	✓	✓	-	-	
	Chrono-tachograph		✓	✓	✓	✓	-	-	
	Injection / ignition	Diesel engine	EDC16C39 SOFIM 3.0 145 CV	✓	✓	✓	✓	-	-
			EDC16C39 SOFIM 3.0 145 CV FAP	✓	✓	✓	✓	-	-
			EDC17CP52 SOFIM 5	✓	✓	✓	✓	-	-
			DCU-102 4HU PUMA 120 CV	✓	✓	✓	✓	-	-
			DCU-102 4HV PUMA 100 CV	✓	✓	✓	✓	-	-
	Airbags		✓	✓	✓	✓	-	-	
	Power steering		✓	✓	✓	✓	-	-	
Pneumatic suspension		✓	✓	✓	✓	-	-		
Additional heating		✓	✓	✓	✓	-	-		
Instrument panel		✓	✓	✓	✓	-	-		
JUMPER3 Minibus	Parking assistance		✓	✓	✓	✓	-	-	
	Telematic		✓	✓	✓	✓	-	-	
	Chrono-tachograph		✓	✓	✓	✓	-	-	
	Injection / ignition	Diesel engine	EDC16C39 SOFIM 3.0 145 CV	✓	✓	✓	✓	-	-
			EDC16C39 SOFIM 3.0 145 CV FAP	✓	✓	✓	✓	-	-
			EDC17CP52 SOFIM 5	✓	✓	✓	✓	-	-
			DCU-102 4HU PUMA 120 CV	✓	✓	✓	✓	-	-
			DCU-102 4HV PUMA 100 CV	✓	✓	✓	✓	-	-
	Airbags		✓	✓	✓	✓	-	-	
	Power steering		✓	✓	✓	✓	-	-	

		Pneumatic suspension	✓	✓	✓	✓	-	-
		additional heating	✓	✓	✓	✓	-	-
JUMPER3 Euro 5		Built-in Systems Interface	✓	✓	✓	✓	-	-
	Engine ECU	EDC17CP52 UDS	✓	✓	✓	✓	-	-
		SID208	✓	✓	✓	✓	-	-
	ABS/ASR	ABS90 F	✓	✓	✓	✓	-	-
		ESP90 F	✓	✓	✓	✓	-	-
		Power steering	✓	✓	✓	-	-	-
		Telematics unit	✓	✓	✓	✓	-	-
		Air conditioning	✓	✓	✓	✓	-	-
		Additional heating	✓	✓	✓	✓	-	-
		Parking aid	✓	✓	✓	✓	-	-
		Airbag	✓	✓	✓	✓	-	-
		Tachograph	✓	✓	✓	✓	-	-
	Electronically managed suspension	✓	✓	✓	✓	-	-	
DS3		Built-in Systems Interface	✓	✓	✓	✓	-	-
	Engine ECU	MEV17_4_2	✓	✓	✓	✓	✓	Initialising the autoadap tives
		MEV17_4_EURO5	✓	✓	✓	✓	✓	Initialising the autoadap tives
		MED17_4_EURO4	✓	✓	✓	✓	✓	-
		EDC16C3	✓	✓	✓	✓	✓	-
		EDC17C10	✓	✓	✓	✓	✓	-
		EDC17C10_BR2	✓	✓	✓	✓	✓	-
		HDI_SID807	✓	✓	✓	✓	✓	-
		HDI_SID807_BR2	✓	✓	✓	✓	✓	-
	Engine ECU	MED17_4_2	✓	✓	✓	✓	✓	Initialising the autoadap tives
		V46	✓	✓	✓	✓	✓	-
	ABS/ASR	ESPMK60_0	✓	✓	✓	✓	✓	-
		ESPMK100	✓	✓	✓	✓	✓	-
	Gearbox	BVA_AL4	✓	✓	✓	✓	✓	-
		BVMP_MA	✓	✓	✓	✓	✓	-
		CFC300P	✓	✓	✓	✓	✓	-
		MAPS_UDS	✓	✓	✓	-	-	-
		Electro-hydraulic power steering (GEP)	✓	✓	✓	✓	✓	-
		Multiplexed additive pump	✓	✓	✓	✓	✓	-
	Battery charge status unit	BECEB	✓	✓	✓	✓	-	-
		BECEB_GEN2	✓	✓	✓	✓	-	-
		Trailer relay unit	✓	✓	✓	✓	-	-
		Engine relay unit	✓	✓	✓	✓	-	-
		Air bag	✓	✓	✓	✓	-	-
		Switch module at the steering wheel	✓	✓	✓	✓	✓	-
		Parking aid	✓	✓	✓	✓	✓	-
		Air conditioning ECU	✓	✓	✓	✓	✓	-
	Multifunction screen (EMF)	Type "A" (segments) AVEC buttons	✓	✓	✓	✓	✓	-
		Type "A" (segments) SANS buttons	✓	✓	✓	✓	✓	-
		Type "C" (dot matrix)	✓	✓	✓	✓	✓	-
		Type "C colour" (dot matrix)	✓	✓	✓	✓	✓	-
		Instrument panel	✓	✓	✓	✓	✓	-
		Hands-free kit (Telephone)	✓	✓	✓	✓	✓	-
	Telematic	RADIONAV_RNEG	✓	✓	✓	✓	✓	-
		RADIONAV_RNEGC	✓	✓	✓	✓	✓	-
		RNEG2010	✓	✓	✓	✓	✓	-
	Radio	RD4	✓	✓	✓	✓	✓	-
		RD45	✓	✓	✓	✓	✓	-
		Alarm	✓	✓	✓	✓	✓	-
		Rain sensor	✓	✓	✓	-	-	-
		Seat belts not fastened LED unit	✓	-	-	-	✓	-
		High frequency receiver	✓	✓	✓	✓	-	-
	Service module	✓	✓	✓	✓	✓	-	
Central voltage retention device	DMTC	✓	-	-	-	-	-	
	DMTR	✓	✓	✓	✓	-	-	
DS3		Built-in Systems Interface	✓	-	-	-	-	-
	Engine ECU	MEV17_4_2	✓	✓	✓	✓	-	-
		MED17_4_2	✓	✓	✓	✓	-	-
		HDI_SID807_BR2	✓	✓	✓	✓	-	-
		EDC17C10_BR2	✓	✓	✓	✓	-	-
		DCM35_BR2	✓	✓	✓	✓	-	-
		MEVD17_4_2	✓	✓	✓	✓	-	-
	ABS/ASR	ME745	✓	✓	✓	✓	-	-
		ABS81	✓	✓	✓	✓	-	-

DS4

ADS/ASR	ESP81	✓	✓	✓	✓	-	-
Gearbox	BVA_AT8	✓	✓	✓	✓	-	-
	CFC300P	✓	✓	✓	✓	-	-
	BVA AM6 AT6 EURO5	✓	✓	✓	✓	-	-
	Power steering electric pump unit	✓	✓	✓	✓	-	-
	Multiplexed additive pump	✓	✓	✓	✓	-	-
	Under inflation detection	✓	✓	✓	✓	-	-
	Discharge bulbs vertical and horizontal adjustment	✓	✓	✓	✓	-	-
	Battery charge status unit	✓	-	-	✓	-	-
	Electric secondary brake	✓	✓	✓	✓	-	-
	Lane departure warning system	✓	✓	✓	✓	-	-
	Trailer relay unit	✓	✓	✓	✓	-	-
	Engine relay unit	✓	✓	✓	✓	-	-
	Air bag	✓	✓	✓	✓	-	-
	Instrument panel	✓	✓	✓	✓	-	-
	Parking aid	✓	✓	✓	✓	-	-
	heating/ventilation	✓	✓	✓	✓	-	-
	Switch module under the steering wheel (Top of column)	✓	✓	✓	✓	-	-
Display	EMF A UDS	✓	✓	✓	-	-	-
	EMF C UDS	✓	✓	✓	-	-	-
	Radio	-	✓	✓	-	-	-
	audio amplifier	✓	✓	✓	✓	-	-
	Telematics	✓	✓	✓	✓	-	-
	Anti-theft alarm	✓	✓	✓	✓	-	-
	Driver's seat memorizing unit	✓	✓	✓	✓	-	-
	Driver's door module	✓	✓	✓	✓	-	-
Matrix screen integral to the instrument panel	Colour matrix screen	✓	✓	✓	-	-	-
	Monochrome matrix screen	✓	✓	✓	-	-	-
	Seat belts not fastened LED unit	✓	-	-	-	-	-
	Rain and brightness sensor	✓	✓	✓	✓	-	-
	Driving school module	✓	-	-	-	-	-
	Independent telematic unit (BTA)	✓	✓	✓	✓	-	-
	Multiplexed control panel	✓	✓	✓	✓	-	-
	Monitoring of the blind spot	✓	✓	✓	✓	-	-
	Steering wheel with integral controls (VCI)	✓	✓	✓	✓	-	-
	Supply protection and management unit	✓	-	-	✓	-	-
	Built-in Systems Interface	✓	-	-	-	-	-
Engine ECU	HDI_SID807_BR2	✓	✓	✓	✓	-	-
	DCM35_BR2	✓	✓	✓	✓	-	-
	MED17_4_2	✓	✓	✓	✓	-	-
	MEVD17_4_2	✓	✓	✓	✓	-	-
	ABS or ESP	✓	✓	✓	✓	-	-
	Gearbox	✓	✓	✓	✓	-	-
	GEP	✓	✓	✓	✓	-	-
	Electric steering lock	✓	✓	✓	✓	-	-
	Battery charge status unit	✓	-	-	✓	-	-
	Multiplexed additive pump	✓	✓	✓	✓	-	-
	Supply protection and management unit	✓	-	-	✓	-	-
	Independent telematic unit (BTA)	✓	✓	✓	✓	-	-
	Telematic navigator	✓	-	-	✓	-	-
	Instrument panel	✓	✓	✓	✓	-	-
	Electric secondary brake	✓	✓	✓	✓	-	-
Matrix screen integral to	Colour matrix screen	✓	✓	✓	-	-	-
	Monochrome matrix screen	✓	✓	✓	-	-	-
	Vibrators control ECU	✓	✓	✓	-	-	-
	Anti-theft alarm	✓	✓	✓	✓	-	-
	Switch module under the steering wheel (Top of column)	✓	✓	✓	✓	-	-
	Hands free starting access electronic module.	✓	✓	✓	✓	-	-
	Electronic key reader	✓	✓	✓	✓	-	-
	Seat belts not fastened LED unit	✓	-	-	-	-	-
	Trailer relay unit	✓	✓	✓	✓	-	-
Display	EMF A	✓	✓	✓	-	-	-
	EMF C	✓	✓	✓	-	-	-
	Rain and brightness sensor	✓	✓	✓	✓	-	-
	Multifunction camera or multifunction video camera	✓	✓	✓	✓	-	-
	Driver's seat memorizing unit	✓	✓	✓	✓	-	-
	Parking aid	✓	✓	✓	✓	-	-
	Under inflation detection	✓	✓	✓	✓	-	-
	High Head Vision	✓	✓	✓	✓	-	-
	heating/ventilation	✓	✓	✓	✓	-	-
	audio amplifier	✓	✓	✓	-	-	-
	Engine relay unit	✓	✓	✓	✓	-	-
	Telematics	✓	✓	✓	✓	-	-
	Discharge bulbs vertical and horizontal adjustment	✓	✓	✓	✓	-	-
	Air bag	✓	✓	✓	✓	-	-
	Steering wheel with integral controls (VCI)	✓	✓	✓	✓	-	-

DS 5

		Multiplexed control panel	√	√	√	√	-	-		
		Radio	-	√	√	-	-	-		
		Clock	√	√	√	√	-	-		
		Windscreen wiper	√	√	√	√	-	-		
DS 5 Hybrid4		Built-in Systems Interface	√	-	-	-	-	-		
	Engine ECU	HDI SID807 BR2	√	√	√	√	-	-		
		DCM35 BR2	√	√	√	√	-	-		
		MED17_4_2	√	√	√	√	-	-		
		MEVD17_4_2	√	√	√	√	-	-		
		ABS or ESP	√	√	√	√	-	-		
		Gearbox	√	√	√	√	-	-		
		GEP	√	√	√	√	-	-		
		Electric steering lock	√	√	√	√	-	-		
		Battery charge status unit	√	-	-	√	-	-		
		Multiplexed additive pump	√	√	√	√	-	-		
		Supply protection and management unit	√	-	-	√	-	-		
		Independent telematic unit (BTA)	√	√	√	√	-	-		
		Telematic navigator	√	-	-	√	-	-		
		Instrument panel	√	√	√	√	-	-		
		Electric secondary brake	√	√	√	√	-	-		
	Matrix screen integral to	Colour matrix screen	√	√	√	-	-	-		
		Monochrome matrix screen	√	√	√	-	-	-		
		Vibrators control ECU	√	√	√	-	-	-		
		Anti-theft alarm	√	√	√	√	-	-		
		Switch module under the steering wheel (Top of column)	√	√	√	√	-	-		
		Hands free starting access electronic module.	√	√	√	√	-	-		
		Electronic key reader	√	√	√	√	-	-		
		Seat belts not fastened LED unit	√	-	-	-	-	-		
		Trailer relay unit	√	√	√	√	-	-		
	Display	EMF A	√	√	√	-	-	-		
		EMF C	√	√	√	-	-	-		
		Rain and brightness sensor	√	√	√	√	-	-		
		Multifunction camera or multifunction video camera	√	√	√	√	-	-		
		Driver's seat memorizing unit	√	√	√	√	-	-		
		Parking aid	√	√	√	√	-	-		
		Under inflation detection	√	√	√	√	-	-		
		High Head Vision	√	√	√	√	-	-		
		heating/ventilation	√	√	√	√	-	-		
		audio amplifier	√	√	√	-	-	-		
		Engine relay unit	√	√	√	√	-	-		
		Telematics	√	√	√	√	-	-		
		Discharge bulbs vertical and horizontal adjustment	√	√	√	√	-	-		
		Air bag	√	√	√	√	-	-		
		Steering wheel with integral controls (VCI)	√	√	√	√	-	-		
		Multiplexed control panel	√	√	√	√	-	-		
		Radio	-	√	√	-	-	-		
		Clock	√	√	√	√	-	-		
		Windscreen wiper	√	√	√	√	-	-		
		Electrical vehicle	√	√	√	-	-	-		
	SAXO	Injection	Petrol engine	1.0L CDY/CDZ BOSCH MA3.1	√	√	√	√	-	-
				1.1L HDY/HDZ BOSCH MA3.1	√	√	√	√	-	-
1.1L HFX BOSCH M7.4.4				√	√	√	√	√	-	
1.4L KFW SAGEM S2000				√	√	√	√	√	-	
1.4L KFW SAGEM S2000				√	√	√	√	√	-	
1.4L KFX MMIAP				-	√	√	-	-	-	
1.4L KFX BOSCH MP7.3				√	√	√	√	√	-	
1.6L NFX MM48P				√	√	√	√	√	Initiali sation of the autoadap tive values	
1.6L NFT BOSCH M7.4.4				√	√	√	√	-	-	
1.6L NFX MMIAP				-	√	√	-	-	-	
1.6L NFZ BOSCH MP5.2		-	√	√	√	-	-			
1.6L NFZ BOSCH MP7.2		√	√	√	-	√	-			
		Anti-lock brake system	-	√	√	-	-	-		
	Airbag	√	√	√	√	-	-			
	Transponder	√	√	√	-	-	-			
ZX	Injection	Petrol engine	1.8L LFY BOSCH MP5.2	-	√	√	√	-	-	
			1.9L D6E BOSCH MA3.1	√	√	√	√	-	-	
			2.0L RFS MMIAP	-	√	√	-	-	-	
		ABS		1.6L BFZ SAGEM CCM4GJ	√	√	√	√	-	-
			ABS BOSCH 5	√	√	√	√	-	-	
			1.4L KFX MMIAP	-	√	√	-	-	-	
			1.4L KFX BOSCH MP7.3	√	√	√	√	√	-	
			1.4L KFX SAGEM SL96	√	√	√	√	-	-	
			1.6L NFZ BOSCH MP5.2	-	√	√	-	-	-	

XSARA (Before 19 January 2000)	Injection	Petrol engine	1.6L NFZ BOSCH MP7.2	✓	✓	✓	—	✓	—
			1.8L LFX MM1AP	—	✓	✓	—	—	—
			1.8L LFY SAGEM SL96	✓	✓	✓	✓	—	—
			2.0L RFS MM1AP	—	✓	✓	—	—	—
			2.0L RFV BOSCH MP5.2	—	✓	✓	—	—	—
		2.0L RGE BOSCH MP5.2	—	✓	✓	—	—	—	
	Diesel engine	1.9L DHV BOSCH AS3-VP20	—	✓	✓	—	—	—	
		2.0L RHY BOSCH EDC15C2	✓	✓	✓	✓	✓	—	
	Air conditioning	220 heating/ventilation		✓	✓	✓	—	—	—
		additional heating		✓	✓	✓	✓	✓	—
	Anti-lock brake system	ABS mechanical distribution		✓	✓	✓	✓	—	—
		ABS electronic distribution		✓	✓	✓	✓	—	—
CPH	Passenger compartment protection ecu		✓	✓	✓	✓	—	—	
	Left hand side airbag		—	✓	✓	—	—	—	
	Right hand side airbag		—	—	✓	—	—	—	
XSARA (After 19 January 2000)		BSI		✓	✓	—	✓	—	—
		Radio post-equipment		✓	✓	✓	✓	✓	—
		CD player		✓	✓	✓	✓	✓	—
		Instrument panel		✓	✓	✓	—	✓	—
		Air conditioning		✓	✓	✓	—	—	—
		additional heating		✓	✓	✓	✓	✓	—
	Injection	Petrol engine	1.4L KFX BOSCH MP7.3	✓	✓	✓	✓	✓	—
			1.4L KFX SAGEM SL96	✓	✓	✓	✓	—	—
			1.6L NFZ BOSCH MP7.2	✓	✓	✓	—	✓	—
			1.8L LFX MM1AP	—	✓	✓	—	—	—
			1.8L LFY SAGEM SL96	✓	✓	✓	✓	—	—
			2.0L RFS MM1AP	—	✓	✓	—	—	—
			2.0L RFV BOSCH MP5.2	—	✓	✓	—	—	—
			1.6L NFZ BOSCH MP5.2	—	✓	✓	—	—	—
	Diesel engine	1.4L KFX BOSCH MP5.2	—	✓	✓	—	—	—	
		1.9L DHV BOSCH AS3-VP20	—	✓	✓	—	—	—	
	Anti-lock brake system	ABS mechanical distribution		✓	✓	✓	✓	—	—
		ABS electronic distribution		✓	✓	✓	✓	—	—
		Airbag		✓	✓	✓	—	—	—
		Left hand side airbag		—	✓	✓	—	—	—
		Right hand side airbag		—	✓	✓	—	—	—
	Auto gearbox	Auto gearbox AL4		✓	✓	✓	✓	—	—
XSARA 2 (Before 1 July 2001)		BSI		✓	✓	✓	✓	—	—
		Navigation		✓	✓	✓	✓	—	—
		Instrument panel		✓	✓	✓	—	✓	—
		Air conditioning		✓	✓	✓	✓	—	—
		Radio post-equipment		✓	✓	✓	✓	✓	—
		Car-phone		✓	✓	✓	✓	✓	—
		CD player		✓	✓	✓	✓	✓	—
		Parking assistance		✓	✓	✓	✓	✓	—
		Top of column		✓	✓	✓	✓	—	—
		Alarm		✓	—	✓	✓	✓	—
		Driving school mode		✓	—	—	✓	—	—
	Display or Autopc	Multifunction display A		✓	✓	—	✓	✓	—
		Multifunction display B		✓	—	✓	✓	✓	—
		Multifunction display C		✓	✓	—	✓	✓	—
		AUTOPC		✓	✓	✓	—	✓	—
	Injection	Petrol engine	2.0L RFN MM48P	✓	✓	✓	✓	✓	Initiali sation of the autoadap tive values
			2.0L RFS MM48P	✓	✓	✓	✓	✓	Initiali sation of the autoadap tive values
			RFN MM4MP2	✓	✓	✓	✓	✓	Initiali sation of auto- adaptati on
			1.6L NFU BOSCH ME744	✓	✓	✓	✓	✓	Initiali sation of auto- adaptati on
		Diesel engine	1.4L KFW SAGEM S2000P	✓	✓	✓	✓	✓	—
			1.9L WJY LUCAS DCN2	✓	✓	✓	✓	✓	—
			RHY SIEMENS SID801	✓	✓	✓	✓	✓	—
8HZ BOSCH EDC16C3 (DV4)			✓	✓	✓	✓	✓	—	

	Anti-lock brake system	ABS electronic distribution	√	√	√	√	√	-	
	Auto gearbox	Auto gearbox AL4	√	√	√	√	√	-	
XSARA 2(After 1 July 2001)	Airbag		√	√	√	-	-	-	
	BSI		√	√	√	√	-	-	
	Navigation		√	√	√	√	-	-	
	Instrument panel		√	√	√	-	-	-	
	Air conditioning		√	√	√	√	-	-	
	Radio post-equipment		√	√	√	√	√	-	
	Car-phone		√	√	√	√	√	-	
	CD player		√	√	√	√	√	-	
	Parking assistance		√	√	√	√	√	-	
	Switch module at the steering wheel		√	√	√	√	-	-	
	Alarm		√	-	√	√	√	-	
	Driving school mode		√	-	-	√	-	-	
	Rain sensor / Brightness		√	√	-	-	-	-	
	Airbag		√	-	√	-	-	-	
	Display or Autopc	Multifunction display A		√	-	-	√	√	-
		Multifunction display B		√	√	-	√	√	-
		Multifunction display C		√	√	√	√	√	-
		AUTOPC		√	√	√	-	√	-
	Injection	Petrol engine	2.0L RFN MM48P	√	√	√	√	√	Initiali sation of the autoadap tive values
			2.0L RFS MM48P	√	√	√	√	√	Initiali sation of the autoadap tive values
			RFN MM4MP2	√	√	√	√	√	Initiali sation of auto- adaptati on
			RFN MM6LP	√	√	√	√	√	Initiali sation of the autoadap tive values
			1.6L NFU BOSCH ME744	√	√	√	√	√	Initiali sation of auto- adaptati on
Diesel engine		1.4L KFW SAGEM S2000P	√	√	√	√	√	-	
		1.9L WJY LUCAS DCN2	√	√	√	√	√	-	
		RHY SIEMENS SID801	√	√	√	√	√	-	
		8HZ BOSCH EDC16C3 (DV4)	√	√	√	√	√	-	
Anti-lock brake system	ABS electronic distribution	√	√	√	√	-	-		
	ESP	√	√	√	√	√	-		
Auto gearbox	Auto gearbox AL4	√	√	√	√	√	-		
	BSI ECU		√	√	√	√	-	-	
	Navigation		√	√	√	√	-	-	
	Multifunction display	Multifunction display VDO B	√	√	√	√	√	-	
		Multifunction display VDO C	√	√	√	√	√	-	
	Air conditioning		√	√	√	√	-	-	
	Radio post-equipment		√	√	√	√	√	-	
	CD player		√	√	√	√	√	-	
	Instrument panel		√	√	√	√	√	-	
			1.6L NFZ BOSCH MP7.2	-	√	√	-	√	-
			1.6L NFV BOSCH M744	√	√	√	√	√	-
			2.0L RFM MM48P	√	√	√	√	√	Initiali sation of the autoadap tive values
			1.8L 6FZ SAGEM S2000P	√	√	√	√	√	-
			6FZ SAGEM S2000PM1	√	√	√	√	√	-
			6FZ SAGEM S2000PM2	√	√	√	√	-	-

XSARA PICASSO (Before 3 November 2002)	Injection	Petrol engine	NFS BOSCH ME745	✓	✓	✓	✓	✓	Initiali se auto- adaptive s
			NFU BOSCH ME745	✓	✓	✓	✓	✓	Initiali se auto- adaptive s
			N6A BOSCH ME745	✓	✓	✓	✓	✓	Initiali se auto- adaptive s
			NFR BOSCH ME745	✓	✓	✓	✓	✓	Initiali se auto- adaptive s
		Diesel engine	2.0L BOSCH EDC15C2	✓	✓	✓	✓	✓	Particle filter and diesel additive maintena nce
	Anti-lock brake system	ABS electronic distribution		✓	✓	✓	✓	✓	-
		ESP		✓	✓	✓	✓	✓	ESP Calibrat ion
	additional heating			✓	✓	✓	✓	✓	-
	Airbag			✓	✓	✓	-	-	-
	Diesel additive function			✓	✓	✓	✓	✓	-
	Left hand side airbag			-	✓	✓	-	-	-
	Right hand side airbag			-	✓	✓	-	-	-
	BSI			✓	✓	✓	✓	-	-
	Navigation			✓	✓	✓	✓	-	-
	Air conditioning			✓	✓	✓	✓	-	-
	Instrument panel			✓	✓	✓	✓	✓	-
	Radio post-equipment			✓	✓	✓	✓	✓	-
	CD player			✓	✓	✓	✓	-	-
	Parking assistance			✓	✓	✓	✓	✓	-
	Alarm			✓	✓	✓	-	✓	-
Switch module at the steering wheel			✓	-	✓	✓	-	-	
Rain sensor / Brightness			✓	-	-	-	-	-	
Diesel additive function			✓	-	-	✓	✓	-	
Airbag			✓	-	-	-	-	-	
Multifunction display	Multifunction display SAGEM B		✓	✓	-	✓	✓	-	
	Multifunction display SAGEM C		✓	✓	✓	✓	-	-	
Service module	STREADOR stolen vehicle location control un		✓	✓	✓	✓	-	-	
XSARA PICASSO (After 3 November 2002)	Injection		RFN MM6LP	✓	✓	✓	✓	✓	Initiali sation of the autoadap tive values
			6FZ SAGEM S2000PM1	✓	✓	✓	✓	✓	-
			6FZ SAGEM S2000PM2	✓	✓	✓	✓	-	-
		Petrol engine	1.6L NFV BOSCH M744	✓	✓	✓	✓	-	Initiali sation of auto- adaptati on
			NFS BOSCH ME745	✓	✓	✓	✓	✓	Initiali se auto- adaptive s
			NFU BOSCH ME745	✓	✓	✓	✓	✓	Initiali se auto- adaptive s
			N6A BOSCH ME745	✓	✓	✓	✓	✓	Initiali se auto- adaptive s
			NFR BOSCH ME745	✓	✓	✓	✓	✓	Initiali se auto- adaptive s

		NFS BOSCH ME749	✓	✓	✓	✓	–	Initialise auto-adaptives
		NFU BOSCH ME749	✓	✓	✓	✓	–	Initialise auto-adaptives
		N6A BOSCH ME749	✓	✓	✓	✓	–	Initialise auto-adaptives
	Diesel engine	2.0L BOSCH EDC15C2	✓	✓	✓	✓	✓	–
		9HY BOSCH EDC16C3 DV6TED4	✓	✓	✓	✓	✓	Specific operation for maintenance and part replacement
		(FAP) BOSCH EDC16C34 DV6	✓	✓	✓	✓	–	–
Anti-lock brake system	ABS8_1_BOSCH		✓	✓	✓	✓	–	–
	ABS8_BOSCH		✓	✓	✓	✓	✓	–
	ABR5_3		✓	✓	✓	✓	–	–
	ESP8_1_BOSCH		✓	✓	✓	✓	–	ESP Calibration
	ESP_BOSCH5.7		✓	✓	✓	✓	✓	ESP Calibration
	ESP8_BOSCH		✓	✓	✓	✓	✓	ESP Calibration
Auto gearbox	Auto gearbox AL4		✓	✓	✓	✓	–	–
	additional heating		✓	✓	✓	✓	✓	–
	BSI		✓	✓	✓	✓	–	–
	Navigation		✓	✓	✓	✓	–	–
	Air conditioning		✓	✓	✓	✓	–	–
	Instrument panel		✓	✓	✓	✓	✓	–
	Radio post-equipment		✓	✓	✓	✓	✓	–
	CD player		✓	✓	✓	✓	✓	–
	Parking assistance		✓	✓	✓	✓	–	–
	Alarm		✓	✓	✓	–	✓	–
	Switch module at the steering wheel		✓	–	✓	✓	–	–
	Rain sensor / Brightness		✓	–	–	–	–	–
	Diesel additive function		✓	–	–	✓	✓	–
	Airbag		✓	–	–	–	–	–
Multifunction display	Multifunction display SAGEM B		✓	✓	–	✓	✓	–
	Multifunction display SAGEM C		✓	✓	✓	✓	✓	–
Service module	STREATOR stolen vehicle location control unit		✓	✓	✓	✓	–	–
	Petrol engine	RFN MM6LP	✓	✓	✓	✓	✓	Initialisation of the autoadaptive values
		6FZ SAGEM S2000PM1	✓	✓	✓	✓	✓	–
		6FZ SAGEM S2000PM2	✓	✓	✓	✓	–	–
		1.6L NFV BOSCH M744	✓	✓	✓	✓	✓	–
		NFS BOSCH ME745	✓	✓	✓	✓	✓	Initialise auto-adaptives
		NFU BOSCH ME745	✓	✓	✓	✓	✓	Initialise auto-adaptives
		N6A BOSCH ME745	✓	✓	✓	✓	✓	Initialise auto-adaptives
		NFR BOSCH ME745	✓	✓	✓	✓	–	Initialise auto-adaptives

ΑΔΑΡΑ PICASSO CHINA	Injection		NFS BOSCH ME749	✓	✓	✓	✓	✓	Initialise auto-adaptives	
			NFU BOSCH ME749	✓	✓	✓	✓	✓	Initialise auto-adaptives	
			N6A BOSCH ME749	✓	✓	✓	✓	✓	Initialise auto-adaptives	
		Diesel engine	2.0L BOSCH EDC15C2	✓	✓	✓	✓	✓	-	
			9HY BOSCH EDC16C3 DV6TED4	✓	✓	✓	✓	-	Particle filter and diesel additive maintenance	
			(FAP) BOSCH EDC16C34 DV6	✓	✓	✓	✓	✓	Specific operation for maintenance and part replacement	
	Anti-lock brake system	ABS8_1_BOSCH		✓	✓	✓	✓	-	-	
		ABS8_BOSCH		✓	✓	✓	✓	✓	-	
		ABR5_3		✓	✓	✓	✓	-	-	
		ESP8_1_BOSCH		✓	✓	✓	✓	-	ESP Calibration	
		ESP_BOSCH5.7		✓	✓	✓	✓	✓	ESP Calibration	
		ESP8_BOSCH		✓	✓	✓	✓	✓	ESP Calibration	
	Auto gearbox	Auto gearbox AL4		✓	✓	✓	✓	✓	-	
		additional heating		✓	✓	✓	✓	-	-	
	XANTIA	Coded anti-theft device			✓	✓	✓	✓	-	-
Injection		Petrol engine	1.8 L LFX MM1AP	-	✓	✓	-	-	-	
			1.8 L LFY BOSCH MP5.1.1	-	✓	✓	✓	-	-	
			1.8 L LFY SAGEM SL96	✓	✓	✓	✓	-	-	
			1.8 L LFZ BOSCH MP5.1	-	✓	✓	-	-	-	
			2.0 L R6E BOSCH MP5.2	-	✓	✓	✓	-	-	
			2.0 L RFT BOSCH MP3.2	-	-	✓	-	-	-	
			2.0 L RFV BOSCH MP5.2	-	✓	-	✓	-	-	
			2.0 L RFV BOSCH MP5.1.1	-	✓	✓	✓	-	-	
			2.0 L RFY BOSCH MP3.2	-	✓	✓	-	-	-	
			2.0 L RGX BOSCH MP3.2	-	✓	✓	-	-	-	
Diesel engine		1.9L DHX BOSCH AS3-VP20	✓	✓	✓	✓	-	-		
		2.1L P8C LUCAS EPIC	✓	✓	✓	✓	-	-		
Air conditioning			✓	✓	✓	-	-			
XANTIA2	Injection	Petrol engine	1.8 L LFX MM1AP	-	✓	✓	-	-		
			1.8 L LFY SAGEM SL96	✓	✓	✓	✓	-		
			1.8L LFY BOSCH MP5.2	-	✓	✓	✓	-		
			1.8L LFY BOSCH MP7.3	✓	✓	✓	✓	✓		
			2.0L R6E BOSCH MP5.2	-	✓	✓	✓	-		
			2.0L RFV BOSCH MP5.2	-	✓	✓	✓	-		
			2.0L RGX BOSCH MP3.2	-	✓	✓	-	-		
			3.0L XFZ BOSCH MP7.0	✓	✓	✓	-	-		
			Diesel engine	1.9L DHX BOSCH AS3-VP20	-	✓	✓	✓	-	-
				2.1L P8C LUCAS EPIC	✓	✓	✓	✓	-	-
	2.0L RHZ BOSCH EDC15C2	✓		✓	✓	✓	✓	-		
	Air conditioning			✓	✓	✓	-	-		
	Additional heating			✓	-	✓	✓	-		
Anti-lock brake system			-	✓	-	-	-			
Airbag			-	✓	✓	-	-			
Right hand side airbag			-	✓	✓	-	-			
Left hand side airbag			-	✓	✓	-	-			
XM(Before 31 May 1994)	Injection	Petrol engine	2.0L RGY BOSCH MP3.2	-	✓	✓	-	-		

EVASION	Injection	Petrol engine	2.0L RFN MM48P	√	√	√	√	√	Initiali sation of the autoadap tive values
			2.0L RGX BOSCH MP3.2	—	√	√	—	—	—
			2.0L RFV BOSCH MP7.3	√	√	√	√	√	—
		Diesel engine	1.9L DHX BOSCH AS3-VP20	—	√	√	—	—	—
			2.1L P8C LUCAS EPIC	√	√	√	√	—	—
			2.0L RHZ BOSCH EDC15C2	√	√	√	√	√	—
			2.0L RHW BOSCH EDC15C2	√	√	√	√	—	—
	Anti-lock brake system	ABS electronic distribution		√	—	√	√	—	—
	Auto gearbox	Auto gearbox AL4		√	√	—	√	√	—
		additional heating		√	√	√	√	√	—
	Airbag		√	√	√	—	—	—	
	CPH	Passenger compartment protencion ecu		√	√	√	√	—	—
C15	Injection			√	√	√	√	√	—
FUKANG/ FUKANG 988	Gearbox ECU	Auto gearbox AL4 TA96		√	—	√	√	—	—
		Auto gearbox AL4 TA2000		√	√	—	√	√	—
	Injection	Petrol engine	1.4L KFX BOSCH MP5.2	—	√	√	—	—	—
			1.6L NFZ BOSCH MP5.2	—	√	√	—	—	—
			1.6L NFU BOSCH ME744						Initiali sation of auto- adaptati on
	Anti-lock brake system	ABS Bosch 5.3		√	√	√	√	—	—
		ABS8.1 BOSCH		√	√	√	√	—	—
	Transponder		√	√	√	√	—	—	
ELYSEE	Gearbox ECU	Auto gearbox AL4 TA96		√	√	√	√	—	—
		Auto gearbox AL4		√	√	√	√	√	—
	Injection	Petrol engine	1.6L NFU BOSCH ME744						Initiali sation of auto- adaptati on
			1.6L NFZ BOSCH MP5.2	—	√	√	—	—	—
			1.4L KFX BOSCH MP5.2	—	√	√	—	—	—
		Anti-lock brake system		√	√	√	√	—	—
	Airbag	Airbag		√	√	√	—	—	—
Sac SIEMNS		√	√	√	√	—	—		
	Transponder		√	√	√	√	—	—	
C-ELYSEE 4	ABS			√	√	√	√	—	—
	Gearbox ECU			√	√	√	√	√	—
	Airbag			√	√	√	√	—	—
	Injection	Petrol engine	1.6 L NFU BOSCH ME744						Initiali sation of auto- adaptati on
			NFU J35	√	√	√	√	√	—
		Transponder		√	√	√	√	—	—
		Central locking control unit		√	√	√	√	—	—
	Built-in Systems Interface		√	—	—	—	—	—	
C-ELYEEM43	Engine ECU	EDC17C10_BR2		√	√	√	√	—	—
		V46 21		√	√	√	√	—	—
		V46		√	√	√	√	—	—
	ABS/ESP	ABS MK100		√	√	√	√	—	—
		ESP MK100		√	√	√	√	—	—
	Multifunction display	EMF_A UDS		√	√	√	—	—	—
		EMF_C UDS		√	√	√	—	—	—
		Switch module at the steering wheel		√	√	√	√	—	—
		Instrument panel		√	√	√	√	—	—
		Parking assistance		√	√	√	√	—	—
	Gearbox	BVA_AT8		√	√	√	√	—	—
		MAPS UDS		√	√	√	—	—	—
		Trailer relay unit		√	√	√	√	—	—
		Radio		√	√	√	√	—	—
		Electric power steering		√	√	√	√	—	—
		Siren		√	√	√	√	—	—
	Airbag		√	√	√	√	—	—	
	Multiplexed additive pump		√	√	√	√	—	—	
	ABS		√	√	√	√	—	—	
	Gearbox ECU		√	√	√	√	√	—	
	Airbag		√	√	√	√	—	—	

C-ELYSEE 5	Injection	Petrol engine	1.6 L NFU BOSCH ME744	✓	✓	✓	✓	✓	Initiali sation of auto- adaptati on	
			NFU J35	✓	✓	✓	✓	✓	-	
	Transponder			✓	✓	✓	✓	-	-	
	Central locking control unit			✓	✓	✓	✓	-	-	
	BSI			✓	✓	✓	✓	✓	-	
C-TRIOMPHE	Instrument panel			✓	✓	✓	✓	✓	-	
	Radio			✓	✓	✓	✓	✓	-	
	CD player			✓	✓	✓	✓	✓	-	
	ABS	ESP8.1 BOSCH		✓	✓	✓	✓	✓	-	
		ESP8 BOSCH		✓	✓	✓	✓	✓	-	
		ABS8.1 BOSCH		✓	✓	✓	✓	✓	-	
		ABS8 BOSCH		✓	✓	✓	✓	✓	-	
	Parking assistance			✓	✓	✓	✓	✓	-	
	Air conditioning			✓	✓	✓	✓	-	-	
	Alarm			✓	✓	✓	✓	✓	-	
	Steering wheel with fixed central controls			✓	✓	✓	✓	✓	-	
	Rain sensor/Brightness			✓	✓	✓	-	-	-	
	Airbag			✓	✓	✓	✓	-	-	
	Multifuntion scree	Multifunction screen C			✓	✓	✓	✓	✓	-
	Telematic	Telematics (RT3)			✓	✓	✓	✓	✓	-
		Telematic (RT4)			✓	✓	✓	✓	✓	-
		Telematics (RT5)			✓	✓	✓	✓	✓	-
	Injection	Petrol engine	RFJ MM6LPB		✓	✓	✓	✓	✓	Initiali sation of auto- adaptati on
			Gearbox ECU Auto gearbox AL4			✓	✓	✓	✓	✓
	Trailer relay unit			✓	✓	✓	✓	✓	-	
Engine relay unit			✓	✓	✓	✓	✓	-		
Power steering			✓	✓	✓	✓	-	-		
Directional headlamps			✓	✓	✓	✓	✓	-		
Hands Free Kit			✓	✓	✓	✓	✓	-		
Driver's door module			✓	✓	✓	✓	✓	-		
Passenger's door module			✓	✓	✓	✓	✓	-		
C-QUATRE 4	BSI			✓	✓	✓	✓	-	-	
	Instrument panel			✓	✓	✓	✓	✓	-	
	Radio			✓	✓	✓	✓	-	-	
	CD player			✓	✓	✓	-	✓	-	
	ABS	ESP8.1 BOSCH		✓	✓	✓	✓	✓	-	
		ABS8.1 BOSCH		✓	✓	✓	✓	✓	-	
	Parking assistance			✓	✓	✓	✓	✓	-	
	Air conditioning			✓	✓	✓	✓	-	-	
	Alarm			✓	✓	✓	✓	✓	-	
	Steering wheel with fixed central controls			✓	✓	✓	✓	✓	-	
	Airbag			✓	✓	✓	✓	-	-	
	Multifuntion scree	Multifunction screen C			✓	✓	✓	✓	✓	-
	Telematic	Telematics (RT3)			✓	✓	✓	✓	✓	-
		Telematic (RT4)			✓	✓	✓	✓	✓	-
		Telematic (RT5)			✓	✓	✓	✓	✓	-
	Injection	Petrol engine	RFJ MM6LPB		✓	✓	✓	✓	-	Initiali sation of auto- adaptati on
			MM6KP Non BioFlex		✓	✓	✓	✓	✓	Initiali sation of auto- adaptati on Replacem ent parts
			MM6KP BioFlex		✓	✓	✓	✓	✓	Initiali sation of auto- adaptati on Replacem ent parts

		N6A BOSCH ME745						Initiali sation of auto- adaptati on	
	Gearbox ECU	Auto gearbox AL4	✓	✓	✓	✓	✓	-	
		Trailer relay unit	✓	✓	✓	✓	✓	-	
		Engine relay unit	✓	✓	✓	✓	✓	-	
		Power steering	✓	✓	✓	✓	-	-	
		Hands Free Kit	✓	✓	✓	✓	✓	-	
		Driver's door module	✓	✓	✓	✓	✓	-	
		Passenger's door module	✓	✓	✓	✓	-	-	
		BSI	✓	✓	✓	✓	✓	-	
		Instrument panel	✓	✓	✓	✓	✓	-	
		Radio	✓	✓	✓	✓	✓	-	
		CD player	✓	✓	✓	-	✓	-	
	ABS	ESP8.1 BOSCH	✓	✓	✓	✓	✓	-	
		ABS8.1 BOSCH	✓	✓	✓	✓	✓	-	
		Parking assistance	✓	✓	✓	✓	✓	-	
		Air conditioning	✓	✓	✓	✓	-	-	
		Alarm	✓	✓	✓	✓	✓	-	
		Steering wheel with fixed central controls	✓	✓	✓	✓	✓	-	
		Rain sensor/Brightness	✓	✓	✓	-	-	-	
		Airbag	✓	✓	✓	✓	-	-	
	Multifunction	Multifuntion screen C	✓	✓	✓	✓	✓	-	
	Telematic	Telematics(RT3)	✓	✓	✓	✓	✓	-	
		Telematic(RT4)	✓	✓	✓	✓	✓	-	
		Telematic(RT5)	✓	✓	✓	✓	✓	-	
C-QUATRE 5	Injection	Petrol engine	RFJ MM6LPB					Initiali sation of auto- adaptati on	
			N6A BOSCH ME745					Initiali sation of auto- adaptati on	
		Gearbox ECU	Auto gearbox AL4	✓	✓	✓	✓	✓	-
			Trailer relay unit	✓	✓	✓	✓	✓	-
			Engine relay unit	✓	✓	✓	✓	✓	-
			Power steering	✓	✓	✓	✓	-	-
			Hands Free Kit	✓	✓	✓	✓	✓	-
			Driver's door module	✓	✓	✓	✓	✓	-
			Passenger's door module	✓	✓	✓	✓	✓	-
					✓	✓			

Remark: ✓ means the system has this function, - means not